

InkZoneMove User Guide

Find more information about the product on our website:
<http://www.digiinfo.com>

Digital Information
Vulkanstrasse 120
CH-8048 Zurich
Switzerland

© Copyright by Digital Information Ltd. 2004 - 2019

The copyright for this technical documentation remains with Digital Information

All rights, including reproduction and distribution rights as well as translation rights, are reserved. No part of the documentation may be reproduced in any form (printing, photocopying, microfilm or other process) without written permission, nor may it be stored, processed, reproduced or distributed using electronic systems.

Every misuse is punishable and requires restitution of damages.

International Cooperation for Integration of Processes in Prepress, Press and Postpress, CIP4, Job Definition Format, JDF and the CIP4 logo are trademarks of CIP4.

Other brand or product names are the registered trademarks or trademarks of their respective holders.

Identifier Installation and configuration manual - English

Target group Operator

Product InkZoneMove

Version v 2.6

Date September 2019

Article code IZM026-EN

Table of Contents


InkZoneMove User Guide	1
1. Screens Online Manual	6
1.1. Measurement View	6
1.1.1. Navigation Bar.....	9
1.1.1.1. Job Setup and Commands	11
1.1.1.1.1. Ink-key Regulation Modifier	15
1.1.1.1.2. Reuse targets from existing Job.....	16
1.1.1.2. Colorbar View.....	18
1.1.1.2.1. IntelliTrax XY coordinates	21
1.1.1.2.2. IntelliTrax XY sample.....	23
1.1.1.3. Target-Setup View	25
1.1.1.4. Scoring View.....	27
1.1.2. Density Relative View	29
1.1.2.1. Target Density.....	32
1.1.2.2. Change Target Density for Single or Grouped Keys.....	34
1.1.2.3. Key Group Selection	35
1.1.2.4. Change Target Density with <Group Ink-Keys> feature.....	37
1.1.3. Density Absolute View.....	38
1.1.4. Colorimetric View	39
1.1.5. BestMatch View.....	41
1.1.6. Dotgain Curve View	43
1.1.7. Dotgain View.....	45
1.1.8. Gray View.....	47
1.1.9. Overprint View.....	49
1.1.10. Paper View	51
1.1.11. Mask Ink-Key & Units	53
1.1.11.1. Masked view.....	54
1.1.12. Job Status.....	55
1.1.12.1. OK-Sheet.....	57
1.1.12.2. Modify OK-Sheet	59
1.1.13. Job Measurement Overview.....	61
1.1.14. Ink-Key Colorbar Patch View	63
1.1.14.1. Single Patch View	65
1.1.15. Measure and Transfer Button.....	67
1.1.16. Spot Measurement	68
1.1.17. Select scoring set	70
1.2. Software Setup	71
1.2.1. Press Setup	71
1.2.1.1. Press Machine Setup.....	74
1.2.1.2. Advanced Press Settings	77
1.2.1.3. Press with Perfector	81
1.2.1.4. Web Press Setup	83
1.2.1.5. Ink-Key Groups	85
1.2.1.5.1. Add - Edit Key Group.....	87
1.2.2. Colorbar Setup	88
1.2.3. Targetset & Print Tolerance Setup.....	90
1.2.3.1. Edit Color.....	93
1.2.3.1.1. Tolerance for Mid-tone and Sheet Consistency.....	97

1.2.3.2. New Targetset	99
1.2.3.2.1. Calibration Curve InkzonePerfect	103
1.2.3.3. Edit Targetset.....	104
1.2.3.4. Standards.....	106
1.2.3.4.1. ISO 12647-2:2013	106
1.2.3.4.1.1. Paper Types	106
1.2.3.4.1.2. TVI Curves	107
1.2.4. Spotcolor Setup.....	108
1.2.4.1. Spot Color View.....	111
1.2.5. Scoring Setup	115
1.2.5.1. Scoring sample - Solids only	119
1.2.5.2. Scoring sample - Solids and TVI	120
1.2.5.3. Scoring Criteria	122
1.2.6. Scanning Device Setup.....	125
1.2.6.1. ColorStation.....	127
1.2.6.2. Demo Instrument	129
1.2.6.2.1. Setup for Demo Purposes.....	131
1.2.6.3. EasyTrax	134
1.2.6.4. GraphoMetronic	136
1.2.6.5. IntelliTrax	138
1.2.6.6. IntelliTrax2	140
1.2.6.7. SpectroDrive	142
1.2.6.7.1. Slope Calibration.....	146
1.2.6.8. SpectroJet.....	147
1.2.6.9. Scan Parameter Setup	149
1.2.6.10. Sheet Orientation	151
1.2.6.10.1. Sheet Orientation IntelliTrax.....	152
1.2.6.11. Measurement Conditions M0 - M1 - M2 - M3	153
1.2.6.12. Instrument Server IZQuattro	155
1.2.6.13. eXact.....	156
1.2.6.13.1. Connect by Bluetooth.....	158
1.2.6.13.2. Connection Status.....	159
1.2.6.13.3. Laser On.....	160
1.2.6.14. SpectroDens	161
1.2.7. System Setup	163
1.2.7.1. Central Database	169
1.2.7.1.1. Sample InkZoneMove with Centralized Database	171
1.2.7.1.2. Firewall Setup	174
1.2.7.2. Database IZTVI.....	178
1.2.7.3. User Management.....	180
1.2.8. Data Export Setup.....	181
1.2.8.1. Export Enable-Disable	184
1.2.8.2. XML Export	185
1.2.8.3. SVF Export	186
1.2.8.4. Alwan Export	187
1.2.8.5. Sakurai	188
1.2.8.6. QCViewer Export	189
1.2.8.7. CTP Curve Optimization	190
1.2.8.7.1. Export rules IZTVI	192
1.2.8.8. PDF Report Template	195

1.2.8.9. E-Mail Schedule.....	200
1.2.9. License Information	201
1.2.10. License Loader	203
1.3. Jobs	204
1.3.1. Home.....	204
1.3.2. New Job	207
1.3.2.1. Spot Color Setup	210
1.3.2.1.1. Colorbar Setup for Spots	212
1.3.2.2. Advanced Job Settings IntelliTrax	214
1.3.2.3. Graphometric Job Setup	215
1.3.3. Job List	216
1.3.3.1. Export Job.....	218
1.3.3.2. Delete Job.....	219
1.3.3.3. Export Job Database	220
1.4. IZReport	221
1.4.1. Setup	221
1.4.2. Views	221
1.4.2.1. Job List.....	222
1.4.2.2. Production Report Summary.....	224
1.4.2.3. Sheet Report Summary	227
1.4.2.4. Sheet Reports	230
1.4.2.5. Trend on Density	232
1.4.2.6. Trend on Lab and TVI	233
1.4.2.7. Sheet Reports with Lab	235
1.4.2.8. PDF output	237
FAQ section	239
How to migrate the job database to another computer?.....	239
Computer with 2 monitors.....	239
Send e-mail with Google Mail server.....	239
Exclude paper white patches with Intellitrap.....	242
Shifted ink-key alignment.....	243
Startup error MSVCR100.DLL	246
Prevent ink-key adjustment with a density threshold parameter.....	246

1. Screens Online Manual

1.1. Measurement View



1 Density relative




See chapter [1.1.2 Density Relative View](#)

2 Density absolute



See chapter [1.1.3 Density Absolute View](#)

3 Colorimetric



See chapter [1.1.4 ColoriMetric View](#)

4 BestMatch



See chapter [1.1.5 BestMatch View](#)

5 TVI curve



See chapter [1.1.6 Dotgain Curve View](#)

6 TVI patches



See chapter [1.1.6. Dotgain View](#)

7 Gray



See chapter [1.1.7. Gray View](#)

8 Overprint



See chapter [1.1.8. Overprint View](#)

9 Paper



See chapter [1.1.9. Paper View](#)

10 Go to Job-Setup view



See chapter [1.1.2. Job-Setup view](#)

11 Go to Navigation



Navigate from here to the job setup, reporting etc. pages

See chapter [1.1.1. Navigation area](#)

12 Go to Change Target Density



Click on the unit number and change target density


See chapter [1.1.2.1. Change target density for all keys](#)

13 Go to Colorbar view



See chapter [1.1.3. Colorbar view](#)

14 Go to Target-Setup view



See chapter [1.1.4. Target-Setup view](#)

15 Go to Scoring view



See chapter [1.1.5. Scoring view](#)

16 Go to job Measurement overview



See chapter [1.1.13. Job Measurement Overview](#)

17 Go to Mask ink key



See chapter [1.1.11. Mask ink key / unit](#)

18 Go to Job Status



See chapter [1.1.12. Job Status](#)

19 Measure and color-control




See chapter [1.1.15. Measure and Transfer Button](#)

20 Ink Key Patch View

See chapter [1.1.14. Ink-Key Patch View](#)

1.1.1. Navigation Bar



1 Home



Click on the logo to return to the home screen

2 Load last used job



Loads the last used job

3 Job list



Loads the job list

4 Reports



Displays the job reports

5 Spot measurement



Changes to the spot measurement window, see here [1.1.16. Spot Measurement](#)

6 Help



Context sensitive help button. Shows a help page for the currently active screen.

7 Configuration




Opens up the software configuration page.

8 Go to Measurement View

[1.1. Measurement view](#)

1.1.1.1. Job Setup and Commands



1 Job information



A click here opens the setup information view from the current job.


2 Job status



Indicates job status as MakeReady / OK-Sheet / Production
Change job status, see here: [1.1.12. Job Status](#)

Status MakeReady





Status OK-Sheet / Production

3


Ink-Key regulation



In the job setup screen click on the unit to display the ink-key regulation modifier.
See here: [1.1.1.1.1. Ink-key Regulation modifier](#)

4

Ink name / Unit number



Displays the ink name and its unit number

5

Job configuration Key Setup and Targets



Select predefined ink-key groups.

See here: [1.1.2.4. Change Target Density with <Group Ink-Keys> feature](#)

-




Set color targets and ink-key mask from existing job, see here: [1.1.1.2. Targets from Existing Job](#)

-

6

Command area

Commands



Click on the logo to return to the home screen



Clone current job



Set current job setup as template nr. 1.
A job template reuses targetset, colorbar,
print sequence and machine setting



Set current job setup as template nr. 2.
A job template reuses targetset, colorbar,
print sequence and machine setting



Create an archive jobs in InkZonePerfect



Creates an ink-preset linearization job in
InkZonePerfect

7

Measurement export

Measurement export



Automatic



Activate the automatic measurement data export such as SVF etc after every scan.



Data from units before perfector



Data from units after perfector

See setup here: [1.2.8. Data Export Setup](#)

8

Go to Measurement View


[1.1. Measurement view](#)

9

[Go to Job Setup](#)

[1.3.2. New Job](#)

1.1.1.1. Ink-key Regulation Modifier




1

Regulation modifier

Change the regulation strength in 5 steps for increase or decrease the strength.

The selected level is indicated in the measurement view top left corner.

In the screenshot below the units for black and cyan were changed for stronger regulation.




2

Go to Job-Setup and Commands[1.1.1.1. Job Setup Information](#)

1.1.1.1.2. Reuse targets from existing Job

[8 Go to Job Setup and Commands](#)



1 Search job



Search here for the job from which the targets should be used

2 Job list

vatel europe
1/12/18 4:22 PM

Job list with all matching jobs to the search criteria

3 Select job

1/12/18
4:22 PM



Select the job with the green button

4 Current setting

Target  1.8

Current target density

5 From selected job

New  1.7


Target density from selected job

6 Target density



Enable new target density for this unit

7 Ink-key mask




Enable ink-key mask for this unit

8 Go to Job Setup and Commands

[1.1.1.1. Job Setup Information](#)

1.1.1.2. Colorbar View



1 Colorbar setup



Click in the colorbar area for detailed information on the measured colorbar and to change the setup.

2 Export colorbar definition




Export the current selected colorbar as a colorbar definition file CBF.

3 Preview scan



Top colorbar shows the colorbar definition, the expected. The colorbar below displays the patch data received from the scanning device.

Click on **Measured** colorbar to preview expected versus measured colorbar:



4 Detected 1st patch

First patch 19

Indicates the number of the first patch from the colorbar definition data. The first patch can be looked when using the IntelliTrax or EasyTrax.


5 Colorbar details and ITX XY setup

Length 747

Indicates the length in mm. Use the XY button to setup the XY parameter for IntelliTrax, see here: [1.1.1.2.1. IntelliTrax XY coordinates](#). Sample setup [1.1.1.2.2. IntelliTrax XY sample](#)

6 Installed colorbars

Change colorbar



Shows all colorbars within InkZoneMove

7 Cancel / Store



Accept or discard changes

8 Active colorbar



Currently selected colorbar

9 Patch assignment


Patch assignments

K	◀	BLACK	▶
C	◀	CYAN	▶
M	◀	MAGENTA	▶
Y	◀	YELLOW	▶

Printed color to colorbar patch assignment. Change with left and right arrow.

10 Go to Measurement View[1.1. Measurement View](#)

1.1.1.2.1. IntelliTrax XY coordinates




1 Paper stops




Align the job sheet to the paper stop when using XY measurement.

2 Instrument head




IntelliTrax head in idle position.

3 Y axis origin



Y axis, starts from paper stop, vertical.

4 X axis origin



X axis, in instrument head movement direction, horizontal.

5 [Return to Colorbar View](#)

[1.1.1.2. Colorbar View](#)


6 [Go to XY ITX sample](#)

[1.1.1.2.2. IntelliTrax XY sample](#)

7 [Go to New Job](#)

[1.3.2. New Job](#)

1.1.1.2.2. IntelliTrax XY sample




1 End point X2




X2 is the distance from the near sheet edge to the **end** of the color patch.

2 Start point X1




X1 is the distance from the near sheet edge to the **beginning** of the color bar.

3 End point Y2



Y2 is the distance from the paper stop to the **center** of the last color patch.

4 Start point Y1



Y1 is the distance from the paper stop to the **center** of the color bar.


5 [Return to ITX XY Coordinates](#)

[1.1.1.2.1. IntelliTrax XY coordinates](#)

6 [Return to New Job](#)

[1.3.2. New Job](#)

1.1.1.3. Target-Setup View



1 Targetset setup area

PSO_P2_B_40-80_V2

Currently selected targetset

2 SCCA color correction

Substrate corrected color aims

Activate SCCA, Substrate Corrected Colorimetric Aims. Corrects the Lab target of solids to match proof and press sheet when the printing substrate to be used has a color that differs from that of the reference printing.

3 Shows data in dry view

Dry view

Displays the measurement data in dry view. Works with any targetset with a wet-dry definition.

4 Available targetsets

Select new

PSO_P1_B_40-80_V2

PSO_P2_B_25-50-75_V2

PSO_P2_B_40-80_V2

PSO_P3_B_25-50-75-V2

List with all defined targetset within IZMove. Color differences and scoring is recalculated after targetset change.

5

Active colorbar

PSO_P2_B_40-80_V2

Currently selected targetset.

6

Go to Measurement View

[1.1. Measurement View](#)

1.1.1.4. Scoring View



1 Score total

51%

Shows total score from the current sheet.

2 Individual score



Shows separate scores for every criterion.

See all criteria here: [1.2.5.3. Scoring Criteria](#)

3 Go to Scoring Setup

[1.2.5. Scoring Setup](#)

4 Go to Measurement View


[1.1. Measurement View](#)

5

Scoring criteria

1.2.5.3. Scoring Criteria

1.1.2. Density Relative View



1 Home



Click on it to return to the home screen

2 Density relative



Displays the density relative view

3 Load last used job



Loads the last used job

4 Job list



Loads the job list

5 Link to spot colors



Changes to the spot color setup.

See [1.2.4. Spotcolor Setup](#)

6 Relative to target



Shows measured density relative to target, like:

Target density 1.35

Measured density 1.40

Displayed value 0.05

7 Unit / Average



Shows average values.

Average values on:

Density

TVI on 40% patches

TVI on 80% patches

DeltaE

8 Target density



Shows currently used target density for the print unit.

Target density is changed by clicking on the unit number.

Then use the plus and minus button for the change.

Or simply type the new target with your keyboard.

See details here: [1.1.1.1. Change target density](#)

9 Mask ink key / unit



Select ink key/s or unit/s which are not regulated with color control.

These key/s are also ignored by the report system.

See here [1.1.10. Mask ink key / unit](#)

10 Production mode



Change to production mode.

IZReport uses only sheets which are marked as "Production" for the production report.

11 OK-Sheet



Sets the currently displayed sheet as an OK-sheet.

The averaged Lab value becomes the new Lab target.

The DeltaE values are recalculated when applying the OK-sheet to a previously scanned sheet.

12 MakeReady



Every new job is initially as MakeReady. Change to OK-sheet or Production mode.

IZReport ignores all MakeReady sheets when a production report is generated.

13 Help



Context sensitive help button. Shows the help page for the currently active screen

14 Configuration




Open up the software configuration page

15 Go to Measurement View

[1.1. Measurement view](#)

1.1.2.1. Target Density



1 Modify target density



Change target density for all ink keys with the +/- buttons

2 Current target density



Indicates the current target density (1.85) with the tolerance area in grey.
Targets and tolerances are set here: [1.2.3. Targetset & Print Tolerance Setup](#)

3 Individual targets



Change to the individual target density setup.
See details here: [1.1.1.2. Change target density for individual keys](#)

4 Go to Density Relative View

[1.1.2. Density Relative View](#)


5 Go to Targets for single or multiple keys

[1.1.2.2. Change Target Density for Single or Grouped Keys](#)


6 Go to Reuse targets from existing job

[1.1.1.1.2. Reuse targets from existing Job](#)

1.1.2.2. Change Target Density for Single or Grouped Keys



1 Activate individual target setup



Set individual target densities for every ink key. Press the plus minus buttons from the key to change targets.

With an ink key group selection several ink keys are changed at once.

See also the feature ink-key groups: [1.1.2.4. Change Target Density with Group Ink-Keys feature](#)


2 Go to Create a group selection

[1.1.2.3. Group Selection](#)

3 Go to <Group Key> feature

[1.1.2.4. Change Target Density with <Group Ink-Keys> feature](#)

1.1.2.3. Key Group Selection




- 1 Start group selection with click**




Click on the first key from an ink-key group. The key start to blink.

- 2 End group selection with click**



After selecting the last ink-key, an ink-key group is selected and is indicated by a green overlay on the plus and minus buttons.

3 **Modify target density**



Change the target density with the plus and minus button


4 **Go to Density Relative View**

[1.1.1. Density Relative View](#)


5 **Go to <Group Key> feature**

[1.1.2.4. Change Target Density with <Group Ink-Keys> feature](#)

1.1.2.4. Change Target Density with <Group Ink-Keys> feature



1 Target change



Change through the plus or minus button the group's ink-keys.

2 Select individual target




Select the icon individual density target and apply target density changes to a range of keys through the +/- buttons from (1)

Note: it's possible to select more than one unit

3 Setup Ink-Key Groups

To setup ink-key groups see here: [1.2.1.5. Ink-Key Groups](#)

1.1.3. Density Absolute View




1 Density absolute



Displays the density relative view

2 Absolute view




Shows measured density in absolute numbers

3 Go to Measurement View

[1.1. Measurement view](#)

1.1.4. Colorimetric View



1 Colorimetric View



Displays colorimetric information

2 DeltaE



Displays DeltaE on every ink-key.

Select the DeltaE method in the target setup, see [1.2.3.2. New Targetset](#)

3 Lab information



Shows Lab target and average DeltaE


4

[Go to Measurement View](#)

[1.1. Measurement view](#)

1.1.5. BestMatch View

Click on the unit number to enable BestMatch target for printing.




1

BestMatch View

Displays BestMatch information with green, yellow and red background for every key.

Background indicator:

- 1) Green = color is okay and within DeltaE defined by the targetset
- 2) Yellow = color is at the edge of the tolerance
- 3) Red = out of tolerance



2

BestMatch target density

BestMatch target density	
Ø BM	1.89
Ø D%	0.37
Ø ΔE	1.52



Shows current BestMatch target. In this sample 1.89.



BestMatch **disabled** (=white background) and 1.89 is the BestMatch target


Standard target density is **enabled**
1.77 is currently active target density



BestMatch **enabled** (=blue background and BM icon next to unit number shows up) and 1.89 is the BestMatch target

Standard target density is **disabled** (=white background)

3

Required density change

Required density change, ink-key change to reach BestMatch DeltaE

4


BestMatch information

Shows BestMatch information

BM target density, averaged

Required density change, averaged


Predicted BestMatch DeltaE when
BestMatch target density is reached



5

Go to Measurement View1.1. Measurement view

1.1.6. Dotgain Curve View




1 View Dotgain Curve



Displays dot gain curves

2 Dotgain curve



Dotgain curves:


- | | |
|------------|---------------------------|
| Grey | expected curve |
| Doted grey | tolerance area |
| Colored | dotgain curve press sheet |

3

[Go to Measurement View](#)

[1.1. Measurement view](#)

1.1.7. Dotgain View




1 View Dotgain



Displays dot gain on measured patches

2 Average value



Average dot gain

3 Target and patch values



Target and measured dot gain

4

[Go to Measurement View](#)

[1.1. Measurement view](#)

1.1.8. Gray View




1 Grey view



Displays grey tone information

2 CMY Densities



Displays C,M and Y density related grey density target.
The targetset 50% grey tone has a density of 0.54

3 DeltaE



Displays DeltaE on each key


4

Target and average


Ø D	0.56
Ø ΔE	5.58
L	59.02
a	0
b	-1

Average density
Average DeltaE

Target Lab



5


Density for CMY

Averaged CMY density on each ink key

6

Go to Measurement View[1.1. Measurement view](#)

1.1.9. Overprint View



1

Overprint view

Displays overprint information


2

Target and average


L	24
a	16
b	-45
Ø ΔE	7.92

Target Lab

Average DeltaE



3

DeltaE


Shows DeltaE on the overprint patches

4

Go to Measurement View


[1.1. Measurement view](#)

1.1.10. Paper View




1 Paper view


Displays information on paper measurement



3 Delta ab



Delta ab values for paper patches


4 L values

L value for paper patches

5 Go to Measurement View**1.1. Measurement view**

1.1.11. Mask Ink-Key & Units

Disable units or single ink-keys in the mask view. The scoring is updated in real time and disabled ink-keys or units are excluded from color-control.



1 Set ink key status



Click on a single ink key or swipe from left to right to change the status of an entire unit
 White tick = not selected (default) = used for scoring and color-control
 Black tick = selected = disabled


2 Go to Measurement View

[1.1. Measurement view](#)


3 Go to Measurement View when key status is disabled

[1.1.10.1. Masked view](#)

1.1.11.1. Masked view



1 Disabled unit



The measurement data is dimmed indicating disabled key / unit

2 Mask key / unit




Mask from here key/s and unit/s
See here [1.1.10. Mask ink key / unit](#)

3 Go to Mask Ink-Key & Units

[1.1.11. Mask Ink-Key & Units](#)

1.1.12. Job Status



1 Job status indicator



Shows the current job status

2 Set Production mode



Change to production mode

3 Set OK-Sheet



Sets the current measurement, the sheet, as the OK-sheet.

See more details here: [1.1.12.1. OK-Sheet](#)

4 Set MakeReady



Every new job is initially in MakeReady status. Change to the status OK-sheet or Production mode.

5

[Go to Measurement view](#)


[1.1. Measurement view](#)

6

[Go to Job Setup View](#)

[1.1.1.1. Job-Setup View](#)

1.1.12.1. OK-Sheet




1 Job status indicator



The icon changes to OK-Sheet

2 Target density is OK



The target density becomes OK

3 OK-Sheet and Production



The buttons OK-Sheet and Production are active

4 Go to Job Status


[1.1.16. Job Status](#)

5

[Go to Modify OK-Sheet](#)

[1.1.12.2. Modify OK-Sheet](#)

1.1.12.2. Modify OK-Sheet



1 Change to OK-Sheet

Open current



5

Opens the current OK-Sheet. In this sample it's sheet number 5.

2 Set new OK-Sheet

Set new



6

Sets the current measurement as the new OK-Sheet, like sheet number 6.

3 Delete OK-Sheet

Clear



Deletes a previously set OK-Sheet and returns to one target density per ink unit.

4

Modify OK-Sheet



When an OK-Sheet is already set and the button is again pressed then 3 options become available to choose from :


1. Change to the currently set OK-Sheet measurement
2. Set the current measurement as a the new OK-Sheet
3. Remove the OK-Sheet

5

Go to Job Status

[1.1.16. Job Status](#)

1.1.13. Job Measurement Overview



1 Current measurement

7 **10:14**

Displays sheet number, front or back side scan and time.
Click on the area to open up the job measurement overview.

2 Job measurement overview

							MakeReady	OKSheet	Production
	7						17:03	15:55	15:56
	1						01/11/16	04/11/16	04/11/16
	2						15:58	15:58	15:58
	3						04/11/16	04/11/16	04/11/16
	4						15:58	15:58	15:58
	5						04/11/16	04/11/16	04/11/16
	6						10:14		
	7								

Displays job measurement history.

3 Delete measurement

7

Deletes the currently selected measurement

4

Side indicator



All scans for top / bottom side are listed here.

Top side (units before perfector)



Bottom side (units after perfector)



5

Measurements

15:55

2

04/11/16

Indicates time and date on a particular measurement

Grey = MakeReady

Green = OK-Sheet

Marin = Production


6

Go to Measurement view

[1.1. Measurement view](#)

1.1.14. Ink-Key Colorbar Patch View


Click on a single measurement to display the density, colorimetric or TVI information data. Note that the display varies by the selected view.



2 Return to Measurement view

3 Go to Single Patch View


1 Select an ink-key



Click on a single measurement to displays density, colorimetric and TVI information for all patches in the selected ink-key. The displayed data depends on the program's selected view.

Ink- key patch data in
Densitometric view

Ink- key patch data in **Colorimetric view**



Ink- key patch data in **Dotgain view**



[D] = measured density / dot gain
 [T] = target density / dot gain
 [ΔD] = density difference

[L] = L value
 [a] = a value
 [b] = b value
 [ΔE] = DeltaE
 [ΔH] = DeltaH

[P] = dot percentage from patch
 [Δ] = difference measured and target dot gain

2 [Return to Measurement view](#)


[1.1. Measurement View](#)

3 [Go to Single Patch View](#)


[1.1.14.1. Single Patch View](#)

1.1.14.1. Single Patch View

Preview all color information from a single patch by clicking on the patch in the ink key view.



1 Spectral remission



Spectral remission in graph and table view.

2 Ink-key and unit number

Key	12
Units	3

Indicates ink-key number and print unit.

3 Select a single patch



Clicking on a patch opens the single patch view.

4 Spectral density

DMax

1.49

Spectral density of the patch by default used for spot colors.

5 Density K C M Y

K	C	M	Y
0.8	1.53	0.47	0.27
1.45			

The four densities calculated by their filters cyan, magenta, yellow and black (visual). The highest density value is automatically highlighted. The top row shows the measured patch the row below is the target value.

6 Color data Lab

L	a	b
52.75	-37.51	-48.43
55	-36	-51

Color values as Lab with top row from measured patch and its target below.

7 Color difference ΔE

3.73

 ΔH

2.74

Calculated DeltaE and DeltaH.

Note: the DeltaE method (CIE76, D2000, etc) is set in the targetset, see chapter [1.2.3.3. Edit Targetset](#)

8 Go to Ink-Key Patch View

[1.1.14. Ink-Key Patch View](#)

9 Go to the Measurement view

[1.1. Measurement View](#)

1.1.15. Measure and Transfer Button

The button on the right starts a scan measurement with the instrument. The one on the left transfers ink-key changes to press console for color-control adjustment.



TRANSFER



SCAN

Return to [1.1. Measurement View](#)

Transfer button for color control

Transfer button turns orange after successfully scanning the press sheet.
Ink key correction for color control is available.

**Scan button**

Progress bar indicates instrument is in scan mode



Progress bar indicates ink-key correction is being transferred to press console



Progress bar indicates instrument finished scan and scan data is displayed



Ink-key correction for color-control is successfully transferred




Automate the transfer by changing the auto-key correction transfer after a scan.
See press setup: [1.2.1.2. Advanced Press Settings](#)

1.1.16. Spot Measurement

Use a spectrophotometer for single spot measurements and compare colors. Apply the measurement as the print target for a spot color.

[7 Go to Navigation Bar](#)



1 Start measurement sample




Place the spectrophotometer over the sample and start measurement.

2 Assign to print unit



First measure the color sample which becomes the print target. Then, apply it as the new Lab and density target to a print unit .

Select the print unit in the upcoming dialog:



3 Paper white calibration



Executes a paper white calibration

4 Select from Targetset



Select a reference color from a targetset

5 Start measurement reference



Place the spectrophotometer over the sample and start measuring

6 Measurement data

Sample	DMax	K	C	M	Y	L	a	b	ΔE 76	ΔE 2000	ΔH	
	0.98	0.17	0.09	0.32	1.01	82.59	13.67	73.06	18.65	8.72	6.58	
Reference	1.7	0.32	0.24	0.44	1.69	72.44	9.18	88.05	-	-	-	


Shows measurement and reference data and their color difference as DeltaE 76, DeltaE 2000 and Delta H

7 Go to Navigation Bar

[1.1.1. Navigation Bar](#)

1.1.17. Select scoring set

Dynamically recalculates the score when changing the scoring



set.

1 Scoring data



Detailed scoring view for single criteria.

Criteria marked as "visible" are shown in this area here. See here:

2 Select scoring



Select from here a scoring set.

Note: it is only possible to select scoring sets which existed during job setup.

Hence, it's not possible to apply a scoring sets which is created after job creation.


Scoring setup, see here: [1.2.5. Scoring Setup](#)

3 Go to Measurement View

[1.1. Measurement View](#)

1.2. Software Setup

1.2.1. Press Setup



1 Printing conditions



Opens the menu Printing conditions with menu entry a) press setup b) Colorbar

2 Menu Press



Open the submenu Press

3 Available machines



All configured press machines are shown here. The current active is marked with a green tick.

4 Machine setup

Name	SM74	Number of keys	23
Machine type	Sheet-fed	Key width	32.5

Shows the press setup. Change the settings by hovering over the press name and click on the setup button on the left.

**5 Active press**

Indicates the current selected press. It is used for all new jobs.

6 Edit press

Hovering with the mouse pointer over the press name brings up the press edit button.

7 Print units

Shows all print units and the standard color sequence.

Press with perfector, see here

8 Create - delete machine

Add with the plus sign a new press or delete the selected one with the cross button.

9 Information

v4.1.0.29

Current version is displayed.

With a click on the software release number more information about the dongle is displayed.

See [1.2.9. License Information](#)

10 Access configuration

Start with the press machine configuration here

11

[Go to Press with Perfector](#)


[1.2.1.2. Press with Perfector](#)

12

[Go to Web Press Setup](#)

See [1.2.1.4. Web Press Setup](#)

1.2.1.1. Press Machine Setup



1 General information

Name	SM102
Manufacturer	Heidelberg


Set here the press machine name and manufacturer.

This values are passed to the measurement data export files such as SVF, XML etc.

2 Machine type

Machine type	Sheet-fed
--------------	-----------

Select either sheet-fed or web press



3 Ink key parameter

Number of keys	32	-	+
Key width	32.5	-	+

Set the number of keys and their width

4 Units and perfector

Units	6	-	+
Perfector position	0	-	+

Set the number of units and the perfector position (if available). For a none perfecting press the position is on 0.

5 Console ink-key setup

Console inkkey direction

Lowest to highest ink key

Typically, on sheet fed press consoles the ink-key number 1 is on the left side and the highest ink-key is on the right. Consequently the ink-key direction is "lowest to highest ink-key". See more on this topic at the web-press setup: [1.2.1.4. Web Press Setup](#)

6 Print units



Press colour setup.

Colour assignment:

First, click on the print unit and then select the color:



7 Ink-Key Groups



With ink-key groups, several ink keys are selected at once to quickly adjust target density. For configuring ink-key groups, see here: [1.2.1.5. Ink-Key Groups](#)

8 Advanced press settings



Configure further press settings. See [1.2.1.3. Advanced Press Settings](#)

9

Go to Press with Perfector

See [1.2.1.3. Press with Perfector](#)


10

Go to Web Press Setup

See [1.2.1.4. Web Press Setup](#)

1.2.1.2. Advanced Press Settings

[10 Return to System Setup](#)





1 Relative view

Density relative values

Applies to the density relative measurement view.


When active measured data shows relative to target instead of the absolute density value.



Absolute view**2****Perfecting Press Setup****Front and back on single page**

It is recommended to activate when configuring the press as a perfecting press.

In the measurement view the control buttons move to the right side to gain more space in height:

**3****Compact view****Hide inactive side keys**


Side ink keys without measurement are not displayed in order to get a more compact measurement data view

Hide active

Side ink keys without measurement data are omitted and not displayed.

**Hide inactive**

All ink keys from press setup are shown even when no measurement data is available for side ink keys.

**4****Same color****Allow same colour in different units**

When active the software allows to use a specific color in more than one print unit

5 Auto transfer

Enable auto ink key transfer

After scanning a press sheet the software automatically transfers data to InkZoneLoop/console for color-control.

6 Sync command

Sync with press before scan

Activate when InkZoneLoop is used. During the scan operation InkZoneLoop synchronizes its ink key position with the press.

7 Color bar position

Colorbar position

Select from the drop down menu one of the two options:

Always centred

Centred and shifted

When selecting **always centred**, the colobar measurement data is aligned centred over the ink-keys. The option **centred and shifted** lets the operator choose how the color bar is aligned. When selecting shifted, the start key is set in the job setup screen.

8 Scan error detection

Enter a density value to detect wrong scan data. When the scan data exceeds the setup value, the key will be not regulated.

Sample:

Target density setup = 1.55


Measurement = 0.3

Setup "disable key for out of range density" = 0.85

Difference of target / measurement = $1.55 - 0.3 = 1.25$


The difference 1.25 exceeds the setup value 0.85. The ink key will be not regulated

An ink-key affected by the "out of range" value is shown with a red warning triangle and is not regulated.



9

Regulation strength




A general regulation change for all units.

10

Return to System Setup

[1.2.7. System Setup](#)

1.2.1.3. Press with Perfector



1 Units before perfector



Print units with color sequence for units before the perfector

2 Perfector position



Perfector indicator and position in the press

3 Units after perfector




Print units with color sequence for units after the perfector

4

[Go to Press Setup](#)

[1.2.1. Press Setup](#)

1.2.1.4. Web Press Setup



1 Machine type

Machine type

Machine

2 Console's ink-key direction



For some web presses with two consoles, one for upper side and one for the lower side units, the ink-key direction on the console desks are not necessarily the same.

On one console side the key nr 1 is on the left which means to use the setting "Lowest to highest inkkey", e.g. 1 to 32.

For the other side, the ink key on the left is the highest and the lowest is on the right, e.g. 32 to 1.

For this case change the ink-key direction to "highest to lowest ink key".

3 Press units

Each print tower indicates an upper and lower print unit.
A press with 4 print towers is setup with 4 units.


Note:

in IZPerfect/Loop version 6 and 7 you still need to setup 8 units for such web press.

4 Go to Press Setup[1.2.1.4. Web Press Setup](#)

1.2.1.5. Ink-Key Groups


How to use <Key Groups> during production, see : [1.1.2.4. Change Target Density with <Group Ink-Keys> feature](#)



1 Job setup

Set key group after job initialization

When active, the user is asked to choose from one of the predefined ink-key groups after initial job setup. Like:



2 Defined groups PRODUCT XYZ PRODUCT ABC MAGAZIN XYZ

<TODO>: Insert description text here...

3 Edit

Edit ink-key group, see here: [1.2.1.5.1. Add - Edit Key Group](#)

4 Add

Add a new ink-key group, see here [1.2.1.5.1. Add - Edit Key Group](#)

5 Delete

Delete an existing ink-key group

6 Return to Press Machine Setup


[1.2.1.1. Press Machine Setup](#)

7 Return to Change Target Density

[1.1.2.4. Change Target Density with <Group Ink-Keys> feature](#)

1.2.1.5.1. Add - Edit Key Group

How to use during production see here:



1 Available ink-keys

1	<table border="1"> <tr><td>1</td><td>2</td><td>3</td><td>4</td><td>5</td><td>6</td><td>7</td><td>8</td><td>9</td><td>10</td><td>11</td><td>12</td><td>13</td><td>14</td><td>15</td><td>16</td><td>17</td><td>18</td><td>19</td><td>20</td><td>21</td><td>22</td><td>23</td></tr> </table>	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23
1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23		

All ink-keys from the press are listed. Select from here the keys

2 Selected keys

9	10	11
---	----	----

Selected ink-keys

3 Key groups

2-6	[2, 3, 4, 5, 6]	<input type="checkbox"/>
9-11	[9, 10, 11]	<input type="checkbox"/>

All ink-key groups are displayed here with the key group's name on the left and the keys on the right.

4 Add key group




Adds a new ink-key group. Set the name and select the ink-keys

5 Delete key group



Delete an existing ink-key group

1.2.2. Colorbar Setup



1 Menu Colorbar



Opens the submenu Colorbar

2 Installed colorbars


- 4c_Goss_4x2-30_v16...
- F105_CS-4
- TCS_300_C6
- TCS_325_C4**

Shows all available colorbars and the currently selected one.

3 Colorbar information

Name	TCS_325_C4				
Manufacturer					
Patches	64	Inks	4	Length	747
Patch width	4.0625	Patch height			6

Detailed colorbar information.

4 Gray CMY values

CMY combination for gray patches.

5 Preview

Preview



Colorbar preview

6 Export colorbar

Exports the selected colorbar

7 Import colorbar

Imports a CBF or STP colorbar definition file.

See the CBF colorbar description here: [CBF Colorbar definition](#)


8 Delete colorbar

Deletes the selected colorbar

9 Create new colorbar

Create a new colorbar with the colorbar editor

1.2.3. Targetset & Print Tolerance Setup



1 Measuring conditions



Opens the menu Measuring Conditions with menu entry **a)** standard printing targetset **b)** spot-color target sets **c)** scoring **d)** scan device setup.

2 Menu

Targetset & Tolerances



Opens the submenu Targetset / Tolerances

3 Available Targetsets

- ISO 12647-2 -2013 PC1 ...
- ISO 12647-2 -2013 PC2 ...
- ISO 12647-2 -2013 PC3 ...
- ISO 12647-2 -2013 PC4 ...
- ISO 12647-2 -2013 PC5 ...

Currently installed targetsets

4

Selected Targetset**PSO_P1_B_40-80_v2**

Currently selected targetset. The shown color entries on the right refer to this target.

Inks	Density	Lab	TVI curve
Black	1.75	19 1 2	B
Cyan	1.45	56 -36 -45	A
Magenta	1.45	46 70 -7	A
Yellow	1.3	84 -4 86	A
Paper	0	89 0 -1	
Blue (C+M)	0.76	27 16 -45	
Green (C+Y)	0.66	49 -57 26	
Red (M+Y)	0.92	46 62 42	
C+M+Y	0.65	27 -4 -1	
Gray 1	0	0 0 0	
Gray 2	0.25	81.36 0 -1.5	
Gray 3	0.54	75.79 0 -1	
Gray 4	0.9	69.99 0 -0.5	
Gray 5	0	0 0 0	



5

Color entries

Inks	Density	Lab	TVI curve
Black	1.85	16 0 0	B
Cyan	1.45	54 -36 -49	A
Magenta	1.4	46 72 -5	A
Yellow	1.35	87 -6 90	A
Paper	0	93 0 -3	

Color entries from selected targetset. Click on the color for editing.

See here: [1.2.3.1. Edit Color](#)

6

Export targetset

Export selected targetset

7

Import targetset

Import targetset data

8

Delete targetset

Delete the currently selected targetset

9

Create new targetset

Create a new targetset.


See [1.2.3.2. New Targetset](#)

10

[Go to ISO Standards](#)

See here: [1.2.3.4.1. ISO 12647-2:2013](#)

1.2.3.1. Edit Color



1 Targetset name

PSO_P2_B_25-50-75_v2

This color is from the targetset indicated here

2 Color name

Yellow

Color name as it appears on the measurement and job setup screen

3 Lab target

L: 87, a: -6, b: 90

Lab target value

4 Target density with tolerance

Density (Y) with tolerance values: -0.1, -0.05, 1.25, 0.05, 0.1

Don't forget to set front and the back side target for perfecting machines.

With this setup the density for front side printing is displayed as:

- < 1.15 red
- 1.15 - 1.19 yellow
- 1.20 - 1.30 green
- 1.31 - 1.35 yellow
- > 1.35 red




5 Front / Back target selector

Density (Y)



Setup an individual density target for front and back side.


6 Spectral remission



Spectral remission curve

7 DeltaE tolerance

ΔE



Color tolerance in DeltaE

With this setup the DeltaE is displayed as:


- $\Delta E < 6$ red
- $\Delta E 5 - 6$ yellow

DeltaE 0 - 5 green



8

TVI values with tolerance



With this setup the TVI curve in the 40% is displayed as:


TVI 40% < 8 red

TVI 40% 8 - 10 yellow

TVI 40% 10 - 16 green

TVI 40% 16 - 18 yellow


TVI 40% > 18 red



9

Visualized TVI curve

TVI curve



TVI curve with targets

10

TVI curve type

Select from a predefined TVI A to F curve or use a linear curve setup

11

Cancel / Store


Dismiss change / accept change

12

Return to Scoring Setup[1.2.5. Scoring Setup](#)

1.2.3.1.1. Tolerance for Mid-tone and Sheet Consistency


When hovering over the left side of the targetset name (see red arrow), the tolerance setup for mid-tone spread and sheet consistency is shown.



1

Mid-tone

Midtone spread tolerance




Set-up tolerances for mid-tone spread.

It compares the TVI mid-tone value (40 or 80%) of C,M and Y.

2

Sheet consistency

Sheet consistency tolerance



Set-up tolerances, deviation from density average, for every printed color.

The sheet consistency density value compares the solid patch distribution to the average density.

A good sheet consistency means that the density across the sheet has been perfectly leveled out:



With a low consistency value, the density across the sheet varies a lot:




3

Go to Scoring Criteria

1.2.5.3. Scoring Criteria

1.2.3.2. New Targetset



1 Targetset name

Name Coated_matt_Paper_ISO

Set an unique name for the color targetset.

A targetset is used for every job to define its color standard

2 IZPerfect calibration curve

Curve name 1_Coated_matt

Select here the ink preset calibration curve used by InkzonePerfect when a new job is prepared.

When a new job is sent from InkzonePerfect to IZMove the "calibration curve" information is passed to IZM. With this information, IZMove loads the corresponding, or let's say linked, targetset in IZMove automatically.

See [1.2.3.2.1. Calibration Curve InkzonePerfect](#)

3 DeltaE method

ΔE formula CIE 76

Select the DeltaE formula to be used.



4

Substrate backing

Backing Black

Choose between black and white substrate backing.

The ITX and ETX are always black backing. ISO requires black substrate backing.



5

TVI curve

TVI version ISO 12647-2 : 2004


Choose between the TVI curve definition from 2004 black and white substrate backing.



TVI 12647-2 2013



TVI 12647-2 2004



Scoring

6

Scoring

ISO 12648

Select the scoring set. See here:

[1.2.5. Scoring Setup](#)

7

Return to Targetset & Tolerance Setup

[1.2.3. Targetset & Print Tolerance Setup](#)

8

Return to Colorimetric View


[1.1.4. Colorimetric View](#)

9

[Return to New Job](#)

[1.3.2. New Job](#)

1.2.3.2.1. Calibration Curve InkzonePerfect



1

Curve name

Calibration Curve:	
<input type="button" value="▼"/>	2_COATED MATT


The calibration curve name is passed to IZMove to select the print targetset.

2

Return to New Targetset

[1.2.3.2. New Targetset](#)

1.2.3.3. Edit Targetset



1 Edit Targetset



Hoover over the targetset and click on edit (pen icon on the left). The targetset setup window is displayed.

2 Targetset parameter

Name	ISO 12647-2 -2013 PC1 BB
Curve name	1_COATED GLOSS
ΔE formula	CIE 76
Backing	Black
TVI version	ISO 12647-2 : 2013
Scoring	ISO

Modify the targetset parameter from here.

See details [1.2.3.2. New Targetset](#)

3

Return to Scoring Setup

[1.2.5. Scoring Setup](#)

4

[Return to Scoring
Sample Solids only](#)

[1.2.5.1. Scoring sample - Solids only](#)

5

[Return to Scoring Sample
Solids-TVI-Overprint-Paper](#)

[1.2.5.2. Scoring sample - Solids-TVI-Overprint-Paper](#)

1.2.3.4. Standards

1.2.3.4.1. ISO 12647-2:2013

[1.2.3.4.1.1. Paper Types](#)

[1.2.3.4.1.2. TVI Curves](#)

1.2.3.4.1.1. Paper Types

There are 8 different paper types listed in the ISO 2013 standard.


	Paper type and surface			
	PS1	PS2	PS3	PS4
Type of surface	Premium coated	Improved coated	Standard glossy coated	Standard matte and semi-matte coated
Typical process	Sheet-fed offset Heat-set web offset	Heat-set web offset	Heat-set web offset	Heat-set web offset
Typical papers	Wood-free coated, gloss, semi-matte, matte (WFC) High and medium weight coated (HWC, MWC)	Medium weight coated (MWC) Light weight coated (LWC Improved)	Light weight coated, gloss and semi-matte (LWC)	Machine finished coated (MFC) Light weight coated, semi-matte (LWC)
	PS5	PS6	PS7	PS8
Type of surface	Wood-free uncoated	Super calendered uncoated	Improved uncoated	Standard uncoated
Typical process	Sheet-fed offset Heat-set web offset	Heat-set web offset	Heat-set web offset	Heat-set web offset
Typical papers	Offset, wood-free uncoated (WFU)	Super calendered (SC-A, SC-B)	Uncoated mechanical improved (UMI) Improved newsprint (INP)	Standard newsprint (SNP)

1.2.3.4.1.2. TVI Curves

List with all print conditions and the corresponding TVI curve type.

Printing Condition (PC)	Print Substrate (PS)	Colorant Description (CD)	Screening Description	
			AM - Periodic	
			TVI Curve	Screen ruling - LPI
PC1	PS1	CD1	A	150 - 200
PC2	PS2	CD2	B	120 - 175
PC3	PS3	CD3	B	120 - 150
PC4	PS4	CD4	B	120 - 150
PC5	PS5	CD5	C	133 - 175
PC6	PS6	CD6	B	120 - 150
PC7	PS7	CD7	C	120 - 150
PC8	PS8	CD8	C	120 - 150

1.2.4. Spotcolor Setup



1 Measuring conditions



Opens the menu Measuring Conditions with menu entry

- a) standard printing targetset
- b) spot-color target sets
- c) scoring
- d) scan device setup.

2 Menu Spot Colors



Open the submenu Spot Colors

3 Shortcut to spot color



Use this shortcut to get directly to the spot color

4 Available targetsets

Customer X

PMS color coated

Currently installed spot color targetset

5 Selected targetset

Customer X

PMS color coated

Inks	Density	Lab	TVI curve
PANTONE 178 C	1.27	63.23 65.43 34.65	Linear
PANTONE 1785 C	1.28	59.6 68.72 28.99	Linear
PANTONE 1787 C	1.26	56.77 72.25 35.67	Linear
PANTONE 1788 C	1.71	53.95 73.81 45.05	Linear
PANTONE 278 C	0.34	72.76 -4.42 -34.67	Linear
PANTONE 3278 C	1.28	53.52 -61.98 1.26	Linear
PANTONE 378 C	1.71	39.53 -11.3 35.46	Linear
PANTONE 478 C	1.61	32.74 23.07 21.78	Linear
PANTONE 578 C	0.62	80.02 -14.14 22.06	Linear
PANTONE 5783 C	0.79	68.06 -6.3 16.59	Linear
PANTONE 5787 C	0.72	75.6 -6.23 21.94	Linear
PANTONE 678 C	0.39	83.45 13.4 -8.33	Linear
PANTONE 7478 C	0.56	84.45 -29.33 6.35	Linear



Current selected spot color targetset.

The shown color entries on the right refer to this target.

6 Color entries

Inks	Density	Lab	TVI curve
PANTONE 178 C	1.27	63.23 65.43 34.65	Linear
PANTONE 1785 C	1.28	59.6 68.72 28.99	Linear
PANTONE 1787 C	1.26	56.77 72.25 35.67	Linear
PANTONE 1788 C	1.71	53.95 73.81 45.05	Linear
PANTONE 278 C	0.34	72.76 -4.42 -34.67	Linear
PANTONE 3278 C	1.28	53.52 -61.98 1.26	Linear

Color entries from selected targetset. Click on the color for editing.

See [1.2.4.1. Spot Color View](#)**7 Search color**

78

Add a part of the spot color name to quickly find the color

8 Import color library




Import a CxF color exchange file

9 Create new spot color



Creates a new spot color:



10 Delete targetset



Deletes the currently selected spot color targetset

11 Create new targetset



Creates a new spot color targetset

12 Export color library



Exports spot color data as CxF

13 Go to Measurement View

[1.1.2. Density Relative View](#)

1.2.4.1. Spot Color View



1 Targetset name

Pantone Coated

The spot color targetset where the color is assigned to

2 Color name

PANTONE 2945 C

Color name

3 Density measurement channel

Channel MAX

Usually the density filter channel for measuring a spot color with a spectrophotometer is set to MAX, meaning the maximum peak from its remission. Nevertheless, it is possible to change the filter to K, C, M or Y

4 Lab target

L 29.34 - + a -4.72 - + b -54.42 - +

Lab target value


5 Target density with tolerance



Target density with tolerance

With this setup the density for a front side measurement is displayed as:

- | | |
|-------------|--------|
| < 1.86 | red |
| 1.86 - 1.90 | yellow |
| 1.91 - 2.01 | green |
| 2.02 - 2.06 | yellow |
| > 2.06 | red |



6 Front / Back target selector



Setup an individual density target for front and back side.


7 DeltaE tolerance




Color tolerance in DeltaE

With this setup the DeltaE for a front and back measurement is displayed as:


- | | |
|----------|--------|
| 0 - 3 | green |
| 3.01 - 5 | yellow |
| > 5 | red |



8 Spectral remission



Spectral remission curve

9 TVI values with tolerance

TVI curve values and their tolerance

10 Visualized TVI curve

TVI curve



Visualized TVI curve with the TVI expected value for 5 to 95%.

11 TVI curve type

ISO 12647-2 uses different sets of predefined TVI curves named A to F.

A linear curve is when the dot gain is expected like

5%Tone TVI=5;

10%Tone TVI=10;

etc.

12 Delete color

Deletes the color

13 Links to an existing color

Create a link to an existing spot color.


Select the reference color in the dialog. Use the search to filter the color list.

The screenshot shows the 'Reference' dialog box. At the top, it says 'Spot colours'. Below that, there's a dropdown menu showing 'Targetset' and 'PMS color coated'. A search bar contains the placeholder 'Search spot name'. Below the search bar is a list of five PANTONE colors: 100 C, 101 C, 102 C, 103 C, and 104 C. To the right of the list is a vertical scroll bar. At the bottom of the dialog is a red button with a white arrow pointing right.

14 Measure with instrument

Place the instrument on the sample and start the color reading with this button. Alternatively, use the instrument measurement button.

1.2.5. Scoring Setup



1 Measuring conditions



Opens the menu Measuring Conditions with menu entry
 a) standard printing targetset
 b) spot-color target sets
 c) scoring
 d) scan device setup

2 Menu scoring



Open the submenu Scoring

3 Scoring set

House standard

ISO (modified)

ISO 12647

Currently available scoring sets.

4 Active

Enabled




Enable / Disable the scoring for the criteria.

5 Display

Visible



Display the criteria on the measurement view in top right corner:



See also the dynamic scoring selection: [1.1.17. Select scoring set](#)

6 Status

Obligatory



Choose if the criteria is obligatory or informative. Only items with status obligatory are used for the total score calculation.

7 Assessment



Setup the scoring value based on the tolerance area green, yellow and red from the targetset.

See the tolerance setup in the targetset here: [1.2.3.1. Edit Color](#)

As an example:

In the targetset, the primary's tolerance is set:

Green	Yellow	Red
DeltaE < 4	DeltaE > 4 and < 5	DeltaE > 5

Cyan

ISO 12647-2 -2013 PC1 WB

L 55 a -36 b -51


Density (C)



-0.1 -0.05 **1.45** 0.05 0.1

ΔE

0 4 5



In this sample, the primary color scoring is set like:

Green	Yellow	Red
-------	--------	-----

Score value = 4

Score value = 3

Score value = 0



Now, let's presume the sheet measurement is:

Average DeltaE's are K = 2.31, C = 3.54, M = 4.52, Y = 5.66

This creates a score as K = 4 points, C = 4 points, M = 3 points, Y = 0 points

Total score = 4 + 4 + 3 + 0 = 11 points (max score is 16 points)

Result in percentage = 11 / 16 * 100 = 68.75%

8

Scoring type

ΔE

ΔE

1/4

Scoring criteria such as primary solids, spot colours, TVI, see details here: [1.2.5.3. Scoring Criteria](#)
Select the DeltaE method in the targetset setup, see here: [1.2.3.3. Edit Targetset](#)

9

Weight on total

Weight

20%

The criteria's weight on the total scoring

10 Manage scoring sets

Add, delete scoring sets. Reuse with import and export functionality.

11 Total scoring setup

Total



Total value shows up in the measurement view in a colored circle on the top right corner.
Setup total score color here.

In this sample the total's color is set like:

Green	68% to 100%
Orange	58% to 68%
Red	0% to 58%

12 Go to Scoring sample

Solids only


[1.2.5.1. Scoring sample - Solids only](#)

13 Go to Scoring sample

Solids-TVI-Overprint-Paper

[1.2.5.2. Scoring set - Solids-TVI-Overprint-Paper](#)

1.2.5.1. Scoring sample - Solids only



1 Targetset

PSO_P2_B_40-80_v2

Selected targetset. Each targetset has a scoring set. See here: [1.2.3.3. Edit Targetset](#)

2 Score solid primaries



66%

Score for the solid primaries CMYK

3 Sheet score


66%

Total score. As only primaries are scored, the total score is equal to the solid primary score

4 Return to Scoring Setup

[1.2.5. Scoring Setup](#)

1.2.5.2. Scoring sample - Solids and TVI



1 Targetset

PSO_P2_B_40-80_V2

Selected targetset with a scoring set. See here: [1.2.3.3. Edit Targetset](#)

2 Score Solids and TVI



Scoring for primaries and TVI.

Configure this view from the scoring set, enable the criteria with the "visible" setting.

See here [1.2.5. Scoring Setup](#)

3 Sheet Score



Total sheet score.


For this sample the score is calculated from the primaries, TVI, overprints and paper patches..

4

[Return to Scoring setup](#)

[1.2.5. Scoring Setup](#)


1.2.5.3. Scoring Criteria



1 Primary colors

ΔE

Scoring on primary colors C M Y and K

2 Spot colors

Scoring spot colors

3 TVI quarter tone

Scoring tone value increase (TVI), quarter tone

4 TVI half tone

Scoring tone value increase (TVI), half tone

5 TVI three quarter tone

Scoring tone value increase (TVI), three quarter tone

6 Mid-tone spread


TVI mid-tone spread on C M Y

7 Solid overprints

Scoring on solid overprints: CM, CY and MY (red, green, blue)

8 Paper Delta E

Scoring on paper, Delta E

9 Paper Delta ab

Scoring on paper, Delta ab

10 Grey 25%

1/4 

Grey value 25%

11 Grey 50%

1/2 

Grey value 50%

12 Grey 75%

3/4 

Grey value 50%

13 Sheet consistency



Sheet consistency, see here: [1.2.3.1.1. Tolerance for Mid-tone and Sheet Consistency](#)

14 Total score

Total


Score on total points



15 Go to Scoring Setup

[1.2.5. Scoring Setup](#)

1.2.6. Scanning Device Setup



1 Measuring conditions



Opens the menu Measuring Conditions with menu entry

- a) standard printing targetset
- b) spot-color target sets
- c) scoring
- d) scan device setup

2 Menu Devices



Menu Devices

3 Active indicator



Indicates which instrument is active.

To change to another instrument, select first the instrument from the device list and then click on the **ACTIVATE**:



Device is not active

ACTIVATE

4

Scanning devices

Lists with all supported scanning devices.

For detailed on the setup see here:

- [1.2.6.1. ColorStation](#)
- [1.2.6.2. Demo instrument](#)
- [1.2.6.3 EasyTrax](#)
- [1.2.6.4. GraphoMetronic](#)
- [1.2.6.5. IntelliTrax](#)
- [1.2.6.6. IntelliTrax2](#)
- [1.2.6.7. SpectroDrive](#)
- [1.2.6.8. SpectroJet](#)
- [1.2.6.13. eXact](#)
- [1.2.6.14. SpectroDens](#)

5

Current setup

Scan parameters

Backing	White	Density polarization filter	
Illuminant	D50	Density white reference	Paper
Density filter	ISO_E	Colorimetric pol filter	
Observer	O2	Colourimetric white ref	Absolute

The instrument current setup. The view may vary for other instruments.

6

Go to IZQuattro

Instrument Server setup

[1.2.6.2. Instrument Server IZQuattro](#)

7

Go to M0-M1-M2-M3 setup

[1.2.6.3. M0 - M1 - M2 - M3 setup](#)


8

Go to sheet orientation ITX

[1.2.6.1. Sheet orientation IntelliTrax](#)

1.2.6.1. ColorStation

The ColorStation is the combination of a high quality large format scanner and the DI-ColorStation software. ColorStation difference to all other scanning devices is by scanning the entire sheet without the necessity of a colorbar. Such a setup reduces paper waste drastically.



1 Scan parameter setup

Scan parameters

Backing	Black	Density polarization filter	<input checked="" type="checkbox"/>
Illuminant	D50	Density white reference	Paper
Density filter	ISO_E	Colourimetric polarization filter	<input type="checkbox"/>
Observer	O2	Colourimetric white reference	Absolute

See details here: [1.2.6.9. Scan Parameter Setup](#)

2 Sheet orientation

Orientation

Reads from	Lowest to highest ink key
Reads from	Lowest to highest ink key

See details here: [1.2.6.10. Sheet Orientation](#)

3 IZQuatro setup

Connection

Quattro Instrument Server mode	<input type="checkbox"/>
--------------------------------	--------------------------

See details here: [1.2.6.12. Instrument Server IZQuattro](#)


4

Go to Scanning Device Setup

[1.2.6. Scanning Device Setup](#)

1.2.6.2. Demo Instrument

The demo instrument acts like a virtual instrument. It allows to virtually scan sheets without having a physical scanning instrument attached.



1 Scan parameter setup

Scan parameters

Backing	Black	Density polarization filter	<input checked="" type="checkbox"/>
Illuminant	D50	Density white reference	Paper
Density filter	ISO_E	Colourimetric polarization filter	<input checked="" type="checkbox"/>
Observer	O2	Colourimetric white reference	Absolute

See details here: [1.2.6.9. Scan Parameter Setup](#)

2 Sheet orientation

Orientation

↙ Reads from	Lowest to highest ink key
↖ Reads from	Lowest to highest ink key

See details here: [1.2.6.10. Sheet Orientation](#)

3 Go to Scanning Device Setup

[1.2.6. Scanning Device Setup](#)

4

Setup for demo purpose


Look up the how-to for using the demo instrument.

See here [1.2.6.2.1. Setup for Demo Purposes](#)


1.2.6.2.1. Setup for Demo Purposes

The Demo Instrument has a set of prepared scan measurement data. The best results are achieved when you following this three steps:


Step 1: Use TCS_325_C4 as the colorbar:




Step 2: Setup the press parameter to 23 keys, key width 32.5mm, 6 units with Perfector off.




Step 3: Enable InkZonePerfect / InkZoneLoop when the programs are installed otherwise turn them both off:



Step 4: Measurement view after first scan



1.2.6.3. EasyTrax



1 Scan parameter setup

Scan parameters

Backing	Black	Density polarization filter	<input checked="" type="checkbox"/>
Illuminant	D50	Density white reference	Paper
Density filter	ISO_E	Colourimetric polarization filter	<input checked="" type="checkbox"/>
Observer	O2	Colourimetric white reference	Absolute

See details here: [1.2.6.9. Scan Parameter Setup](#)

2 Sheet orientation

Orientation

↙ Reads from	Lowest to highest ink key
↖ Reads from	Lowest to highest ink key

See details here: [1.2.6.10. Sheet Orientation](#)

3 IZQuatro setup

Connection

Quatro Instrument Server mode	<input checked="" type="checkbox"/>
-------------------------------	-------------------------------------

See details here: [1.2.6.12. Instrument Server IZQuatro](#)

4

Specifications


Producer	X-Rite
Min. patch width	3.8mm
Min. patch height	4.0mm
Size	29" and 40"
Connected by	Ethernet
Comment	no M1 reading, legacy product

5

Go to Scanning Instrument Setup[1.2.6. Scanning Device Setup](#)

1.2.6.4. GraphoMetronic

Inline measurement system for web presses may by GraphoMetronic.



1 Scan parameter setup

Scan parameters

Backing	Black	Density polarization filter	<input checked="" type="checkbox"/>
Illuminant	D50	Density white reference	Paper
Density filter	ISO_E	Colourimetric polarization filter	<input type="checkbox"/>
Observer	O2	Colourimetric white reference	Absolute

See details here: [1.2.6.9. Scan Parameter Setup](#)

2 Sheet orientation

Orientation

Y Reads from	Lowest to highest ink key
X Reads from	Lowest to highest ink key

See detail here: [1.2.6.10. Sheet Orientation](#)

3 Web parameter

Connection

Show warning after minutes of scan inactivity	3	-	+
Measurements skipped after wash	1000	-	+


Setting top Warning when no new scan data is received after "x" minutes.
This helps to identify an instrument error or a network connection problem to the GM processing unit.

Setting below ignores x sheets for color-control after blanket wash

4

Return to Scanning Device Setup[1.2.6. Scanning Device Setup](#)

1.2.6.5. IntelliTrax



1 Scan parameter setup

Scan parameters

Backing	Black	Density polarization filter	<input checked="" type="checkbox"/>
Illuminant	D50	Density white reference	Paper
Density filter	ISO_E	Colourimetric polarization filter	<input checked="" type="checkbox"/>
Observer	O2	Colourimetric white reference	Absolute

See details here: [1.2.6.9. Scan Parameter Setup](#)

2 Sheet orientation

Orientation

Reads from	Highest to lowest key
Reads from	Highest to lowest key

See details here: [1.2.6.10.1. Sheet Orientation IntelliTrax](#)

3 IZQuattro setup

Connection

Quatro Instrument Server mode	<input checked="" type="checkbox"/>
-------------------------------	-------------------------------------

See details here: [1.2.6.12. Instrument Server IZQuattro](#)

4


[Go to Scanning Device Setup](#)[1.2.6. Scanning Device Setup](#)

5

Specifications

Producer	X-Rite
Min. patch size	standard spot size 3.2mm small spot (option) 2.0mm polarization (option) 3.5mm
Size	29" to 65"
Connected by	Ethernet
Comment	no M1 reading, legacy product

1.2.6.6. IntelliTrax2



1 Scan parameter setup

Scan parameters

Backing	Black	Density polarization filter	<input checked="" type="checkbox"/>
Illuminant	D50	Density white reference	Paper
Density filter	ISO_E	Colourimetric polarization filter	<input type="checkbox"/>
Observer	O2	Colourimetric white reference	Absolute

See details here: [1.2.6.9. Scan Parameter Setup](#)

2 Sheet orientation

Orientation

↙ Reads from	Highest to lowest key
↖ Reads from	Highest to lowest key

See details here: [1.2.6.10.1. Sheet Orientation IntelliTrax](#)

3 Scan modes

Scan mode	M0
-----------	----

See here the measurement conditions: [1.2.6.11. Measurement Conditions M0 - M1 - M2 - M3](#)

4 IZQuattro setup

Quattro Instrument Server mode	<input type="checkbox"/>
--------------------------------	--------------------------

See details here: [1.2.6.12. Instrument Server IZQuatro](#)

5 Go to Scanning Device Setup

[1.2.6. Scanning Device Setup](#)

6 Specification

Producer X-Rite

Min. patch size standard spot size 3.0mm
small spot (option) 2.0mm
polarization (option) 3.0mm


Size 29" to 65"

Connected by Ethernet

Measurement Conditions M0, M1, M3

Comment supports M1 reading
replaces IntelliTrax1

1.2.6.7. SpectroDrive



1 Measure track length



Starts measuring the rail length and stores it afterwards to the instrument.

2 Slope Calibration



Instrument calibration to be used with a color reference chart or to adjust density values to a 3rd party instrument.

See here: [1.2.6.7.1. Slope Calibration](#)

3 Scan parameter setup

Scan parameters

Backing	Black	Density polarization filter	<input checked="" type="checkbox"/>
Illuminant	D50	Density white reference	Paper
Density filter	ISO_E	Colorimetric pol filter	<input type="checkbox"/>
Observer	O2	Colourimetric white ref	Absolute

See details here: [1.2.6.9. Scan Parameter Setup](#)

4 Sheet orientation

Orientation	
Reads from	Lowest to highest ink key
Reads from	Lowest to highest ink key

See details here: [1.2.6.10. Sheet Orientation](#)

5 Generation

Device generation

2

Generation 2 is for the latest one called SpectroDrive.NG, includes M1 reading
Generation 1 is for the predecessor with M0 only reading

6 Serial number

Serial B711528 

Serial number of the currently connected SpectroDrive.
Use the unlock button "x" to disconnect InkZoneMove from the instrument.

7 WI-FI Channel

Wireless channel

Automatic

Change here from the automatic channel selection to a fixed channel.
See details in the troubleshooting section: [1.2.6.7. SpectroDrive](#)

8 Measurement condition

Scan mode M0

See here the instrument measurement conditions: [1.2.6.11. Measurement Conditions M0 - M1 - M2 - M3](#)

9 IZQuatro setup

Quattro Instrument Server mode 


See details here: [1.2.6.12. Instrument Server IZQuatro](#)

10 Troubleshooting

If you experience continuously connection problem to the device than try using a fixed WLAN channel.

Do like:

1. Download a WLAN channel scanner app to your mobile



2. Find the channel with the lowest traffic
3. Change in the configuration "Wireless channel" from Automatic to a fixed channel. Channel 2 to 11 are valid.



4. Quit InkZoneMove and unplug and replug the Techkon USB WLAN box. Restart InkZoneMove. Finish

Specifications

11

Producer	Techkon
Min. patch size	3.0mm
Size	20" to 80"

Connected by	WLAN module
Measurement Conditions	M0, M1, M2, M3
Comment	supports M1 with SpectroDriveNG



12 [Return to Scanning Device Setup](#)**[1.2.6.9. Scan Parameter Setup](#)**

1.2.6.7.1. Slope Calibration


Start the slope calibration and follow the step by step procedure:

1. Measure the paper white of the reference chart.
If this has been just before then skip it.


2. Type in the reference density data, the values the instrument should read, for black, cyan, magenta and yellow. The values are taken from the reference chart or from the readings of a 3rd party instrument.



3. Measure the reference for black, cyan, magenta and yellow and press continue.




4. Review the settings and submit them with the green button.



Return to SpectroDrive instrument setup [1.2.6.7. SpectroDrive](#)

1.2.6.8. SpectroJet



1 Scan parameter setup

Scan parameters

Backing	Black	Density polarization filter	<input checked="" type="checkbox"/>
Illuminant	D50	Density white reference	Paper
Density filter	ISO_E	Colourimetric polarization filter	<input type="checkbox"/>
Observer	O2	Colourimetric white reference	Absolute

See details here: [1.2.6.9. Scan Parameter Setup](#)

2 Sheet orientation

Orientation

Y Reads from	Lowest to highest ink key
X Reads from	Lowest to highest ink key

See details here: [1.2.6.10. Sheet Orientation](#)

3 IZQuattro setup

Connection

Quattro Instrument Server mode	<input type="checkbox"/>
--------------------------------	--------------------------

See details here: [1.2.6.12. Instrument Server IZQuattro](#)

4


Specifications

Producer	Techkon
Min. patch size	3.0mm
Scan length max	2000 mm
Connected by	serial cable
Measurement Conditions	M0, M1, M2, M3
Comment	supports M1 reading with SpectroJetNG

5

Return to Scanning Device Setup[1.2.6. Scanning Device Setup](#)

1.2.6.9. Scan Parameter Setup



1 Instrument backing

Backing **Black**

Set instrument backing to black or white (substrate backing).

Note: the targetsets are linked to the backing parameter white or black.
A white backing selection in the instrument setup will force the software to show only white backing targetsets whereas a black selection shows only black targetsets.

2 Illumination

Illuminant **D50**

Select the illumination.

3 Density filter

Density filter **ISO_E**

Select the density filter.

4 Observer

Observer **O2**

Select the observer.

5 Polarization density

Density polarization filter

Activate/deactivate the polarization filter for density reading

6 White reference density

Density white reference **Paper**

Select the white reference for density measurement.

7 Polarization colorimetric

Colourimetric polarization filter

Activate/deactivate the polarization filter for colorimetric reading

8


White reference colorimetric

Colourimetric white reference Absolute

Select the white reference for colorimetric measurement.

1.2.6.10. Sheet Orientation

Colorbar patch direction in job setup window.



Instrument setup at press console:

Case 1
Instrument head reads sheet like shown:

Console keys

Key:1 —————→ Key: 32

Scan direction = Lowest to highest key
Console ink key = Lowest to highest
The 1st patch is on the left (the cyan patch in the above example)

Case 2
Instrument head reads sheet like shown:

Console keys

Key:1 —————→ Key: 32

Scan direction = Highest to lowest key
Console ink key = Lowest to highest
The 1st patch is on the left (the cyan patch in the above example)


1 [Return to Scan Instrument Setup](#)

1 [Return to Scan Instrument Setup](#)


[1.2.6. Scanning Device Setup](#)

1.2.6.10.1. Sheet Orientation IntelliTrax

Colorbar patch direction in the job setup window.



Instrument setup at press console:




1 Return to
Scan Device Setup

1 [Return to
Scan Device Setup](#)


[1.2.6. Scan Device Setup](#)

1.2.6.11. Measurement Conditions M0 - M1 - M2 - M3

IntelliTrax2, eXact EAS, SpectroDriveNG, SpectroJet and SpectroDens support M1 reading (ISO specification 13655)



1 Scan mode



Select the colorimetric scan mode for IntelliTrax2 and SpectroDriveNG:

M0 legacy mode

M1 defined by the new standards ISO-13655 / ISO-3664

M2 UV-cut

M3 polarized


See details here : http://issuu.com/konicaminoltabeu/docs/iso13655_demystified_e/1?e=0

2

[Return to Device Setup](#)

[1.2.6. Scan Device Setup](#)

1.2.6.12. Instrument Server IZQuattro



1

IZQuattro Server Setup

Connection

Quattro Instrument Server mode

Path C:\Users\cede\Documents\InstrumentServer


Activate here the **IZQuattro Instrument Server mode** and set the communication path between the two programs.

2

Go to Scan Device Setup

[1.2.6. Scan Device Setup](#)

1.2.6.13. eXact



1 Scan parameter setup

Scan parameters

Backing	Black	Density polarization filter	<input checked="" type="checkbox"/>
Illuminant	D50	Density white reference	Paper
Density filter	ISO_E	Colorimetric pol filter	<input checked="" type="checkbox"/>
Observer	O2	Colourimetric white ref	Absolute

See details here: [1.2.6.9. Scan Parameter Setup](#)

2 Sheet orientation

Orientation

↙ Reads from	Lowest to highest ink key
↖ Reads from	Lowest to highest ink key

See details here: [1.2.6.10.1. Sheet Orientation IntelliTrax](#)

3 Patches

Patches 200 - +

Setup here the maximum number of patches to be scanned from the full sheet.

4 Scan modes

Scan mode ▾

See here the measurement conditions: [1.2.6.11. Measurement Conditions M0 - M1 - M2 - M3](#)

5

Go to Scanning Device Setup

[1.2.6. Scanning Device Setup](#)

6

Specification

Producer X-Rite

Patch size min. 3.0mm with aperture size 1.5mm

min 4.0mm with aperture size 2 mm

More details are here:

[Min Patch size X-Rite tech support](#)

Size up to 65"

Connected by USB and Bluetooth
See: [1.2.6.13.1. Connect by Bluetooth](#)


Measurement Conditions M0, M1, M3

Comment supports automated scanning
replaces EasyTrax

1.2.6.13.1. Connect by Bluetooth

From X-Rite support page:

You must use the pairing code '**default**' (no quotes) when pairing a BlueTooth-enabled eXact to a PC. Pairing the BlueTooth-enabled eXact handheld incorrectly can result in the appearance of a connection, but the device will not interact with X-Rite software.



Step by step pairing procedure:

1. Insert the supplied BlueTooth dongle into an available USB port. Windows will automatically search for and find the proper drivers.

Make sure that BlueTooth is activated on the eXact by going to My Settings>Instrument>BlueTooth and selecting 'On'.

2. In the Windows Toolbar (in the lower right corner) click the BlueTooth icon and select 'Add a Device'. A window will open and will populate with available BlueTooth devices. Note that it may take several seconds before the available devices are identified by name in the list. Any eXact with activated BlueTooth that are in range will show up in the list and will be identified by their serial number.

3. Select the eXact from the list that you wish to pair. Click 'Next'.

4. You will be presented with Pairing options. Select '**Use the device's pairing code**' and click 'Next'.

5. In the next window, confirm that you are connecting to the correct device and enter the **eXact's pairing code**: '**default**' (do not type the single quotes).

6. A message will appear that the eXact has been successfully paired and device drivers will be loaded.

1.2.6.13.2. Connection Status


The instrument changes the Bluetooth symbol from **grey** to **blue** when a computer successful connects to it. A grey symbol means no connection!




1.2.6.13.3. Laser On

Switch on the eXact autoscan line laser (1) in the instrument dialog, accessible from lower right corner. The laser stays on for 30 seconds.

There is no button to switch it off manually.



1.2.6.14. SpectroDens



1 Scan parameter setup

Scan parameters

Backing	Black	Density polarization filter	<input checked="" type="checkbox"/>
Illuminant	D50	Density white reference	Paper
Density filter	ISO_E	Colorimetric pol filter	<input type="checkbox"/>
Observer	O2	Colourimetric white ref	Absolute

See details here: [1.2.6.9. Scan Parameter Setup](#)

2 Sheet orientation

Orientation

Reads from	Lowest to highest ink key
Reads from	Lowest to highest ink key

See details here: [1.2.6.10. Sheet Orientation](#)

3 Connection

Connection

Scan mode	M0
Enable Wifi	<input checked="" type="checkbox"/>
Device IP address	192.168.43.6

Setup the SpectroDens IP configuration with SpectroConnect.

See document here: [SpectroDens Wlan Setup](#)

For IZM, setup the IP address and enable the Wifi setting.
An USB connection is used when the Wifi setting is off.

4

Specifications


Producer	Techkon
Min. patch size	6 mm without contrast bar (patch separator)
Scan length max	200 patches in 10 sec
Connected by	USB or WiFi
Measurement Conditions	M0, M1, M2, M3
Comment	Colorbar scanning for color-control is only supported with SpectroDens Premium

5

Return to Scanning Device Setup

1.2.6. Scanning Device Setup

1.2.7. System Setup



1 Connected modules



Opens the menu Connected modules with menu entry

- a) System
- b) Data-Export

2 Menu System



Opens the submenu System

3 InkZonePerfect




When InkZonePerfect (ink-preset) is installed on the same computer then enable it here.

After the activation, a new job from always starts from InkZonePerfect by selecting the prepared CIP3 data with job name and color separation.

Note


The current job path is correctly pre-selected. Change the path only when required.

Job setup in InkZonePerfect, see here: [1.2.3.2.1. Calibration Curve InkzonePerfect](#)



4 InkZoneLoop

InkZoneLoop



Setting Enable/Disable

With InkZoneLoop installed on the same computer, enable the application in IZMove here.

All measurement data created by InkZoneMove is sent to the selected scan data folder to be processed by InkZoneLoop.

Setting: Disable key for out of range density

Set a density threshold to detect wrong scan data. When the scan data values exceed the threshold will cause no regulation for this particular ink-key.

Sample:

Target density setup = 1.55


Measurement = 0.3

Setup "disable key for out of range density" = 0.85

Difference of target / measurement = $1.55 - 0.3 = 1.25$

The difference 1.25 exceeds the setup value 0.85. The ink key will be not regulated

An ink-key where the density is detected as "out of range" is shown with a red warning triangle and is not regulated at the press.



With InkZoneLoop installed, verify the **synchronize** option (needs to be activate) in the press setup.

See here: [1.2.1.2. Advanced Press Settings](#)

5 InkZoneReport

InkZoneReport

Company name and logo

Select company name and logo which appears on the report print out

Company name	DI
Company logo path	C:\logos\logo_digiinfo_cmyk.tif  

PDF job name setup

Setup a job name with the parameters in brackets for generating the job name for PDF sheet and production reports:

Printed report filename template

<job>, <date>, <time>, <sheet_number>, <sheet_report>, <production_report>

Sheet report	<job>_<sheet_report>_<date>_<time>_<sheet_
Print Production-Report	<job>_<production_report>_<date>_<time>

<job> job name

<sheet_report> if the term Sheet-Report appears in the name

<production_report> if the term Production-Report appears in the name

<date><time> date and time

<sheet_number> sheet number

E-Mail report setup

Sends PDF reports over e-mail.

Setup mail server SMTP host address and port. Define the e-mail sender's address.

See further information on sending mails through Google Mail: [Send e-mail with Google Mail server](#)

Email sending

SMTP host	smtp.gmail.com	SMTP port	465
Use authentication	<input checked="" type="checkbox"/>	Username	Press room SM102-6
Send mail as	pressroom@gmail.com		

E-Mail recipients

Create an alias with one or a group of e-mail recipients. For a group of recipients, use a semi-colon to separate the mail addresses.

An alias is either internal or external. This helps avoiding mistakes when sending reports.

The rule is that e-mails defined as internal can be send always whereas external addresses are sent only when customer name from the job setup matches the e-mail alias name.

See setup customer name here: [1.3.2. New Job](#)


Approved recipients

Name	QC	Email address	qc@printer.com	Address type	Internal	
Name	PrintBuyer1	Email address	purchase@prnbuyer.com	Address type	Customer	

6

InkZoneTVI**InkZoneTVI**

Displays information about the current compensation data set for a given press and targetset which both are selected from the drop down list:



7

IZKomoriConnect**IZKomoriConnect**

InkZoneKomoriConnect links to the Komori PDCS closedloop application

IZKomoriConnect enabled			
1	Komori CLC program	C:\PDCS	<input checked="" type="checkbox"/>
2	CLC version	3	3 <input checked="" type="radio"/> COM port <input type="radio"/> COM1
4	ClosedLoop mode	Semi Auto	<input type="radio"/>
5	Wait for both sides before sending PDCS data		<input checked="" type="checkbox"/>

- 1 Komori CLC program Set the path to the Komori CLC program. Usually it is located in folder C:\PDCS
- 2 CLC version Select 3 or 4 (double check what is installed)
- 3 COM port COM port used by the CLC program
- 4 Closedloop mode Semi- and full auto. Standard is semi auto which requires the operator to confirm ink-key changes at the console desk. The setting Auto changes ink-keys immediately after transfer.
- 5 Wait for both sides... Enable when using a perfecting press. Data is sent to press when both sides are scanned

When using an IZSwitchbox than configure the parameters here:



1 IP address set IP address , usually 192.168.0.99

2 Relay channel usually channel 1 is used

Use job name information from Komori KMS:



1 Path Select the path to the status folder within KMS

2 Project and job name Form the IZMove job name by project and job name from KMS

8 Measurement Devices

Devices

The **command path** is used to communicate to InkZonePerfect / Loop and needs to be set in these programs to the same location.

The **scan path** for the measurement data delivered by the scan instrument drivers IntelliTrax, EasyTrax, Graphometronic or SpectroJet.

The colorbar path is populated by InkZoneMove with the colorbar information file CBF for the scan instrument driver

Note: the default directories are correctly set and therefore change only when required.

Commands path	C:\Users\ceede\AppData\Roaming\DI\InkzoneMove\comm	
Scans path	C:\Users\ceede\AppData\Roaming\DI\InkzoneMove3\press	
Colorbar path	C:\Users\ceede\AppData\Roaming\DI\InkzoneMove3\press	

9 Archive

Jobs archive

The oldest jobs are automatically archived to the selected **archive path** when the condition **free disk space** is less than **x %** of the disk drive.

Database size / free space remaining	17.0 MB / 25%
Archive jobs if free percentage is less than	15%
Archive path	

10 Central Database**Central database**

Use a centralized database for jobs and spot colors.

The local database automatically synchronizes to the main database and vice versa.

11 User Setup**User management**

Enable the user management here. Add and modify existing user.

Enable user accounts

Users

admin  

 CREATE USER

12 Touchscreen**Touchscreen**

Enables features to run optimized for touch-screen controlled PC.

Enable touchscreen features

1.2.7.1. Central Database

Select one of the tabs **Spot Colours**, **IZTVI** or **Report Jobs** and configure the synchronization to a main database.

	SPOT COLOURS	IZTVI
Settings Server 1	Server 1	
Pull setup	Enabled	
	IP address	192.168.17.88
	Pull data	
Push setup	Status	, 6/20/2018 10:21 PM
	Push data	
	Status	Unknown
Settings Server 2	Server 2	
	Enabled	
	IP address	192.168.17.89
	Pull data	
	Status	, 6/20/2018 10:21 PM
	Push data	

1 Settings Server 1

Server 1	
Enabled	
IP address	192.168.17.88
Pull data	
Status	, 6/20/2018 10:21 PM
Push data	
Status	Unknown

Shows all settings for server 1, including the connection status to the remote couchDB

2 Pull setup

Pull data
Status

Enable pull data to sync data from the remote server to the local database. All data from the remote database is synchronized to the local database.

First, set IP address and then enable it. The last status of the connection is shown.

3 Push setup



Enable push data to sync data from the local database with the remote server database. All data from the local database is synchronized to the main database.

First, set IP address and then enable it. The last status of the connection is shown.

4 Settings Server 2

Server 2	
Enabled	
IP address	192.168.17.89
Pull data	
Status	6/20/2018 10:21 PM
Push data	


Settings for next server

5 Delete




Delete the server setup.

1.2.7.1.1. Sample InkZoneMove with Centralized Database




1 Main database



Settings for PC with main database (192.168.1.1)

The database can run on Linux or Windows. For couchDB v2 a 64 bit operating system is mandatory.
It's required to open the TCP port 5984, see Windows firewall setup: [1.2.7.1.2. Firewall Setup](#)

2 Clients with local databases



Test at the InkZoneMove client

After changing the firewall setup on the server, every IZM client (192.168.1.2. etc) is able to access remotely the servers couchdb configuration through a web browser, like:

http://SERVER_IP:5984/_utils/config.html (replace SERVER_IP with the real ip address)

username inkzone
password testing

Name	Size	Number of Documents	Update Seq
_replicator	4.1 KB	1	1
_users	4.1 KB	1	1
inkzone-central	0.6 MB	227	2298
inkzone-colors	16.1 KB	28	121
inkzone-jobs	11.0 MB	50	9183
inkzone-jobs-report	79 bytes	0	0
inkzone-logs	3.8 MB	9467	9467
inkzone-move	3.2 MB	22	43
inkzone-report	3.0 MB	22	43
inkzone-scoring	25.6 MB	14483	23671

Showing 1-10 of 61 databases

← Previous Page | Rows per page: 10 | Next Page →

Tools
Overview
Configuration
Replicator
Status
Documentation
Manual
Diagnostics
Verify Installation
Recent Databases
_replicator

Welcome InkZone
Setup more admins or
Change password or Logout
Futon on Apache CouchDB 1.6.1

You should see the couchdb data from the server database.

Setup InkZoneMove at the client PC

IZTVI	
Enabled	<input type="checkbox"/>
IP address	192.168.17.117
Pull data	<input type="checkbox"/>
Status	<input type="checkbox"/>
Push data	<input type="checkbox"/>
Status	<input type="checkbox"/>

Set in “Central database/Spot Colours/IZTVI/Report” the server IP address and enable Pull and Push data.

Every new spot color is automatically propagated to the server database from where all other IZMove clients pull the spot color data to their local database.

Important

After creating a new spot color targetset, like “Pantone coated”, restart the clients IZMove to get it visualized in the client IZMove.

Note

The restart is not required after a new spot colors has been created, the restart applies only for targetset creation.

Verify replication status on client

- a) On the client open the link

http://localhost:5984/_utils/database.html?_replicator

to see the replication status page:

b)

Key	Value
"_design/_replicators"	{...}
"_replicator"	{...}
"inkzone-spots-pull"	{...}
"_replicator"	{...}
"inkzone-spots-push"	{...}
"_replicator"	{...}

Click on “inkzone-spots-pull”

c)

Field	Value
"_id"	"inkzone-spots-pull"
"_replication_id"	"401a7446d11e4d10fe403fda3b7ed70"
"_replication_state"	1 "triggered"
"_replication_state_time"	"2017-12-16T14:34:00+01:00"
"_rev"	"2-42ab235ce20cc47228594feb56bd60"
"_continuous"	true
"_create_target"	true
"_owner"	"inkzone"
"_source"	"http://inkzone:testing@192.168.17.74:5984/inkzone-spots"
"_target"	"http://inkzone:testing@127.0.0.1:5984/inkzone-spots"


- 1) Should say “triggered”
- 2) Source address points to the IZM database server
- 3) Target is the local PC

1.2.7.1.2. Firewall Setup

On the main database server, the port 5984 needs to be opened.


Configuration:

a)




Open Firewall setting


b)



Create a new "Inbound Rule"




Select “New Rule”




Select Port

e)




Port address is 5984

f)




Allow for all connections

g)



Enable all networks


h)



Give the new rule a useful name. Finish!

1.2.7.2. Database IZTVI

Select tab IZTVI and configure synchronization to the IZTVI database for compensation data.



1 Setup to IZTVI 1

Enabled	<input checked="" type="checkbox"/>
IP address	192.168.17.65
Pull data	<input checked="" type="checkbox"/>
Status	6/20/2018 10:23 PM
Push data	<input checked="" type="checkbox"/>
Status	

Configuration and status of connection to server 1.

2 Pull data from remote DB

Pull data	<input checked="" type="checkbox"/>
Status	6/20/2018 10:23 PM

InkZoneTVI data is pulled from the remote InkZoneTVI database to the local database. The second line shows the status of the last execution.

3 Add



Synchronize data to another InkZoneTVI station.

4 Delete




Deletes the synchronization setup.

5 Push data to remote DB

Push data	<input checked="" type="checkbox"/>
Status	

Data for InkZoneTVI is pushed to the remote InkZoneTVI database . The second line shows the status of the last execution.

1.2.7.3. User Management




1 Activate

Enable user accounts

Enable the user management. After startup, the user can log in with his account. The user names are recorded for every job and is printed on the IZReport.

The operator can logout from a session from the dashboard screen.



2 User

Users

Edgar

Henry

admin



Manage all user from here. The admin account can not be deleted.

3 Edit

Create a new password or delete the user.

4 Add

Add a new user

1.2.8. Data Export Setup

11 Go to Job Setup and Command 10 Go to Export Enable / Disable

Menu Data Export 1

XML export 2

SVF export 3

Alwan export 4

Sakurai 5

QCViewer export 6

CTP Compensation 7

Report PDF 8

E-Mail 9

11 Go to Job Setup and Command 10 Go to Export Enable / Disable

Connected to Demo Instrument

1 **Menu Data Export**

Sub menu Data Export

2 **XML export**See here: [1.2.8.2. XML Export](#)**3** **SVF export**See here: [1.2.8.3. SVF Export](#)**4** **Alwan export**See here: [1.2.8.4. Alwan Export](#)**5** **Sakurai**See here: [1.2.8.5. Sakurai](#)**6** **QCViewer export**See here: [1.2.8.5. QCViewer Export](#)**7** **CTP Compensation**See here: [1.2.8.6. CTP Compensation Export](#)**8** **Report PDF**Setup a PDF report template, see here: [1.2.8.8. PDF Report Template](#)**9** **E-Mail**

Schedule an e-mail when a job is considered as finish.

See here: [1.2.8.9. E-Mail Schedule](#)**10** **Go to
Export Enable / Disable**


1.2.8.1. Export Enable-Disable

11


Go to
Job Setup and Command

1.1.1.1. Job Setup Information

1.2.8.1. Export Enable-Disable



1 Auto export on / off



By default the automatic export is active and every measurement is automatically exported. When it is disabled than export a single measurement with the buttons on the right.

2 Manual export




Manually exports measurement data according to the Data Export setup, see here:
[1.2.8. Data Export Setup](#)

3 Go to Data Export Setup

[1.2.8. Data Export Setup](#)

1.2.8.2. XML Export

Exports the generic data measurement format by InkZone. It contains color data for every measured patch.



1 Export on / off

Automatic export for new data

Activate the **automatic** option to **export** every measurement

2 Destination folder

Path


Select the destination folder

3 Go to Data Export Setup

[1.2.8. Data Export Setup](#)

1.2.8.3. SVF Export

Exports the X-Rite SVF measurement format. It contains color data for every measured patch.



1 Export on / off

Automatic export for new data



Activate the **automatic** option to **export** every measurement

2 Destination folder

Path



Select the destination folder

3 Spot color density

Use spectral density for spots




Use spectral density data for spot colors instead of densities from the C,M,Y,K filter set

4 Go to Data Export Setup

[1.2.8. Data Export Setup](#)

1.2.8.4. Alwan Export

Exports for the data format for Alwan Print Standardizer. It contains color data for every measured patch.



1 Export on / off

Automatic export for new data

Activate the **automatic** option to **export** every measurement

2 Destination folder

Path


Select the destination folder

3 Go to Data Export Setup

[1.2.8. Data Export Setup](#)

1.2.8.5. Sakurai

Exports the Sakurai color control data file. It contains color data for every measured patch.



1 Export on / off



Activate the **automatic** option to **export** every measurement

2 Destination folder




Select the destination folder

3 Go to Data Export Setup

[1.2.8. Data Export Setup](#)

1.2.8.6. QCViewer Export

Exports the data format for QCViewer.



1 Export on / off

Automatic export for new data



Activate the **automatic** option to **export** every measurement

2 Destination folder

Path




Select the destination folder

3 Go to Data Export Setup

[1.2.8. Data Export Setup](#)

1.2.8.7. CTP Curve Optimization

Configure the datasets export for InkZoneTVI. Based on the data InkZoneTVI creates compensation curves for the workflow RIP. The exported data is based on job runs.



1 Export setups

Export schedule

Press	Heidelberg CD10	Targetset	Carton_v2018	<input type="button" value="▼"/>
Press	Heidelberg CD10	Targetset	PSO_Coated_v2	<input type="button" value="▲"/>
Enabled				<input checked="" type="checkbox"/> <input type="checkbox"/>
Run every				7 <input type="button" value="-"/> <input type="button" value="+"/> days
Skip MakeReady measurements				<input checked="" type="checkbox"/>
ΔE tolerance	6 <input type="button" value="-"/> <input type="button" value="+"/>	Density tolerance ±	0.5 <input type="button" value="-"/> <input type="button" value="+"/>	
Measurements required for valid export				5 <input type="button" value="-"/> <input type="button" value="+"/>

All export rules are listed here. Expand them with the arrow up/down on the right side.
See the rules details here:

2 Expand rule



View rule set for a combination of press and targetset

3 **Delete rule**



Remove the rule

4 **Run rule once**



Use for testing the setup by running the rule once.

5 **Export result**

Timestamp	Jobs used / total	Avg dE / Avg D
2018-06-01T11:52:10.000	1 / 1	5.32 / 1.54 4.25 / 1.57 3.04 / 1.49 7.64 / 1.03

Lists all runs and their result

6 **Add rule**



Add a new rule

7 **Go to Rule Setup**


[1.2.8.6.1. Export rules IZTVI](#)

8 **Go to Data Export Setup**

[1.2.8. Data Export Setup](#)

1.2.8.7.1. Export rules IZTVI

Setup the export rules for CTP plate compensation curves.



1 Export rule collapsed

Press Heidelberg CD1 Targetset Carton_v2018

Export rule with press and targetset name. Expand it to review the setup and see processed jobs with the arrow down button on the right.

2 Press

Press Heidelberg CD1

Select the press from the list box

3 Targetset

Targetset PSO_Coated_v2

Select the targetset from the list box

4 Schedule

Run every 7 - + days

The rule is repeated every "number" of "days/weeks"

5 Tolerances

ΔE tolerance

6



Density tolerance ±

0.5



Measurement data exceeding DeltaE or density are ignored during export

6**Add**

Create a new rule

7**Job list**

Timestamp	Jobs used / total	Avg dE / Avg D
2018-06-01T11:52:10.000	1 / 1	5.32 / 1.54 4.25 / 1.57 3.04 / 1.49 7.64 / 1.03

Every export is listed here with date, number of used jobs and their DeltaE, Density averages

8**Run**

Test the setup from here and see the expor data in IZTVI

9**Measurements**

Measurements required for valid export

5



Number of measurements required to create an export

10**Activate filter set**

Skip MakeReady measurements



All data is ignored which do not match the setup rules

11**Activate / Delete**

Enabled



Enable the rule. Delete it with the red cross on the right

12 Export rule expanded

Press	Heidelberg CD100	Targetset	PSO_Coated_v2				
Enabled	<input checked="" type="checkbox"/>						
Run every	7			days			
Skip MakeReady measurements	<input checked="" type="checkbox"/>						
ΔE tolerance	6			Density tolerance ±	0.5		
Measurements required for valid export				5			


Export rule expanded view

13 Return to CTP Curve Compensation

[1.2.8.6. CTP Curve optimization](#)

1.2.8.8. PDF Report Template

Create templates with print out elements. A template is selected during the PDF report creation. See here: [1.2.8.8. PDF Report Template](#)



1 Template name

Name	Standard
------	----------

Define a template name. The template can be selected when creating a PDF.

2 Elements

Job details	<input checked="" type="checkbox"/>	Instrument and scoring setup	<input checked="" type="checkbox"/>
Summary	<input checked="" type="checkbox"/>	Dot gain	<input checked="" type="checkbox"/>
Signature	<input type="checkbox"/>	Lab graphs	<input type="checkbox"/>
Dot gain graphs	<input checked="" type="checkbox"/>	G7 graphs	<input type="checkbox"/>
CTP status	<input type="checkbox"/>		

Set the template item to **active** to include it to the PDF report print out.

3 Job details

Job details	<input checked="" type="checkbox"/>
-------------	-------------------------------------

Template item Job details

Adds job information, including the total score, to the PDF report:

Report type / Job name / Nr of measurements / Customer name / Date-Time / Assessment Sample:

Job details	
Report type	Print Production-Report
Job name	AGRI INK - KONGRESBLAD 2017 INSIDE WT84310_3A
Number of measurements	4
Customer	
Date	07/04/2017 12:08 PM
Assessment	Pass, score 87%

4 Instrument and scoring

Instrument and scoring setup

Template item **Instrument and scoring**

Adds scan instrument the print standard targetset to the PDF report:

Targetset / Scoring set / Instrument backing / Illuminant, observer and measurement condition (Mx)

Sample:

Instrument and scoring setup	
Targetset	PSO_P1_B_25-50-75_v2
Scoring	ISO 12647
Backing	Black
Illuminant / Observer / Condition	D50 / O2 /

5 Summary

Summary

Template item **Summary**

Adds a table with color and TVI assessment to the PDF report.

Read columns as:

- [1] Print / Target [Lab] : printed value in bold, target values in light color tone
- [2] Density : target density
- [3] Delta E / Tolerance : deltaE of printed color in bold, accepted tolerance for assessment in light color tone
- [4] Delta E score : scores for deltaE with the selected scoring set
- [5] Dot gain score : scores for dot gain values with the selected scoring set
- [6] Midtone spread: scores for mid-tone spread

Sample:

		1			2	3	4	5
		Print / Target [L a b]			D	ΔE / Tol	ΔE	
Black		16.0 / 16.0	0.8 / 0.0	1.9 / 0.0	1.80	5.4 / 5	<div style="width: 75%;"><div style="width: 100%;">75%</div></div>	<div style="width: 100%;">100%</div>
Cyan		54.4 / 54.0	-35.9 / -36.0	-50.4 / -49.0	1.50	1.7 / 5	<div style="width: 100%;">100%</div>	<div style="width: 100%;">100%</div>
Magenta		49.0 / 46.0	74.8 / 72.0	-4.5 / -5.0	1.39	4.5 / 5	<div style="width: 100%;">100%</div>	<div style="width: 80%;">80%</div>
Yellow		87.9 / 87.0	-5.8 / -6.0	88.7 / 90.0	1.31	2.8 / 5	<div style="width: 100%;">100%</div>	<div style="width: 100%;">100%</div>
Red (M+Y)		48.5 / 46.0	68.5 / 67.0	45.8 / 47.0	1.53	3.9 / 10	<div style="width: 100%;">100%</div>	<div style="width: 100%;">100%</div>
Green (C+Y)		49.0 / 49.0	-68.7 / -66.0	21.7 / 24.0	1.46	3.8 / 10	<div style="width: 100%;">100%</div>	<div style="width: 100%;">100%</div>
Blue (C+M)		25.3 / 24.0	16.8 / 16.0	-46.8 / -45.0	1.45	2.7 / 10	<div style="width: 100%;">100%</div>	<div style="width: 100%;">100%</div>
Paper		93.4 / 93.0	1.1 / 0.0	-2.7 / -3.0	0.00	1.3 / 3	<div style="width: 100%;">100%</div>	<div style="width: 100%;">100%</div>

6

Signature

Signature

**Template item Signature**

Adds at the bottom of the PDF report a customer sign-off element.

Sample:

Comments	Signed
	Place and date
	Sign

7

Dot gain

Dot gain

**Template item Dot gain**

Adds dot gain information to the PDF report.

Sample:

	Target ± Tolerance					
	25%	50%	75%	25%	50%	75%
Black	12.1 ± 4	17 ± 4	13.4 ± 3	✓ 11.33	✓ 16.46	✓ 13.24
Cyan	9.3 ± 3	14.3 ± 3	12.3 ± 3	✓ 12.24	✓ 10.32	✓ 10.65
Magenta	9.3 ± 3	14.3 ± 3	12.3 ± 3	⚠ 5.53	✓ 9.92	✓ 10.07
Yellow	9.3 ± 3	14.3 ± 3	12.3 ± 3	✓ 8.57	✓ 12.66	✓ 12.21

8


Dot gain graphs

Dot gain graphs

**Template item Dot gain graphs**

Adds dot gain graphs to the PDF report.

Sample:



9 CTP status

CTP status

Template item **CTP status**

Adds information about data exported by InkZoneTVI to the PDF report.


10 Lab graphs

Lab graphs

Template item **Lab graphs**

Adds a color gamut circle to the PDF report.

Sample:



11 G7 graphs

G7 graphs

Adds a G7 graphs to the PDF report.

12 Add



Creates a PDF template which is available during PDF report creation.

13

Delete



Delete the PDF template.


14

Go to Data Export Setup

[1.2.8. Data Export Setup](#)

1.2.8.9. E-Mail Schedule

Schedule the automatic generation of an E-Mails after the job is finished. The e-mail contains the production report created with the selected PDF template. A job is considered as finish when a new one is created.



1 Activate

Enable automatic email scheduling

Activate the e-mail scheduling here. After activation, a PDF report is sent to the e-mail address after the job ends.

The end of a job is considered when a new job is created.

2 Select PDF template

Template Standard ▾

Select a defined template for the PDF creation, see here: [1.2.8.8. PDF Report Template](#)


3 Configure E-Mail

Email address

Choose the e-mail recipient.

Setup the mail server settings here: [1.2.7. System Setup](#)

1.2.9. License Information



1 Version

InkZoneMove version

Currently installed software version

2 Dongle

Dongle id

Dongle hardware ID. See also the blue identification label attached to the dongle

3 Valid for

Dongle max version

Dongle is valid for shown version number or lower

4 Expires

License expiration

License expires on the given date

5 More modules

Additional modules

Further licensed modules on this dongle

6 Start license loader




Starts the license loader module. Request a new license with the license loader.

See [1.2.10. License Loader](#)

 [Return to Press Setup](#)

[1.2.1. Press Setup](#)

1.2.10. License Loader



1 Refresh dongle information



Refresh the shown dongle information

2 Load License

Load license

Load a license file to change the dongle status

3 License request

Request extended license


Creates a license request file. Send it to your dealer or distributor

4 Return to License Information

[1.2.9. License Information](#)

1.3. Jobs

1.3.1. Home



1 Home



A click on the icon returns you to the home screen (this screen)

2 Load current job



Opens current job in measurement view

3 Job list



Changes to job list

4 Reports



Displays the report from currently active job, see here [1.4.2.3. Report summary](#)

5 Status info

System status

Active device	Demo Instrument
Active press	Heidelberg CD102
Current job	W23452_Brochure_Form03_Front

Displays job name and currently active press setup and the selected instrument.

6 Open active job



Opens current job in measurement view

7 Create new job



Start a new job from here

8 Help




Context sensitive help button. Brings up a help page from the currently active IZM4 page

9 Configuration



Change to the software configuration page

10 Trend



Trend graphs for printed jobs. Vertical bars indicate job score. Trend lines in different color for Primary, Spot Colour, TVI, Overprint, Gray, Paper and Midtone Spread

11 Configure trend

Last

30 jobs




Change trend display from **number of jobs** to **last x days**, modify the number.

12

How to use the help

Hover over the number to get extra information or a link to the topic.




13

Link to Online HTML Manual

[InkkZoneMove Online User Guide](#)

1.3.2. New Job



1 Job name

Job name

When the job starts from InkZonePerfect the name is automatically set and refers to the CTP / CIP3 job name scheme from the prepress workflow.

2 Customer name

Customer

Add a customer/print buyer name to the job.

IZReport can send PDF reports to customers. For this scenario, it is important that the customer name set here matches the one in the e-mail setup, see here: [1.2.7. System Setup](#)

3 Confirm / Cancel



Confirm or cancel job setup

4 Colorbar

Colour bar TCS_325_C4 Patch height 6 

Colorbar for the front side print.

When printing with perfector, the back side colorbar needs to be set too.

Define spot color patches in the colorbar, see here: [1.3.2.2. Spot color job](#)

5 Targetset

Targetset / Paper ISO 12647-2 -2013 PC1 BB

Print targetset.

When job starts from InkZonePerfect the targetset is set automatically .

How to link the ink-preset calibration curve from InkZonePerfect to a targetset see here: [1.2.3.2. New Targetset](#)

6 Colorbar height

Patch height 6 

When using an IntelliTrax, the colorbar height needs to be set here.

7 Colorbar



Preview of the selected colorbar

8 Advanced Colorbar



Align the measurement data related to the ink-keys either centred (standard) or shifted.

See details here: [Shifted ink-key alignment](#)

9 Advanced for ITX



In advanced setup set the colorbar position with XY coordinate values when using an IntelliTrax scanner. Go to Intellitrax XY colorbar setup: [1.3.2.2. Advanced Job Settings](#)

10 Job template



Select a predefined template job. A template job has a defined targetset, colorbar, color sequence and machine type.

See here how to set a template job: [1.1.1.1. Job-Setup View](#)

11 Print units



Print unit with target density and its assigned color. Click on the unit to add or change a color.

12 Got to Spot color setup

[1.3.2.1. Spot color setup](#)


13 Return to Job List

[1.3.3. Job List](#)

14 Job setup
Graphometronic

See here: [1.3.2.3. Graphometronic Job Setup](#)

1.3.2.1. Spot Color Setup



1 Select unit first



Click on the unit to open the assignment dialog

2 Select CMYK or empty


Standard colours



Select from here one of the process colors **CMYK** or set the units as **empty**, none printing

3 Select spot color targetset

Spot colours



When using a spot color then select the target set first

4

Search / Filter



274

Add a search string to filter the selection

5

Spot color list

- PANTONE 274 C
- PANTONE 2745 C
- PANTONE 2746 C
- PANTONE 2747 C
- PANTONE 2748 C



Select the color from the filtered spot color list

6

Return to New Job


[1.3.2. New Job](#)

7

Go to Colorbar setup for spot

[1.3.2.1.1. Colorbar setup for spot](#)

1.3.2.1.1. Colorbar Setup for Spots



1 Colorbar

1 Colour bar TCS_300_C6

Select an appropriate colorbar for a spot color job. In the sample a 6 patch colorbar is selected.

2 Preview

2 Patch assignments

Preview the patch to color assignment.

3 Patch to color

K		BLACK	
C		CYAN	
M		MAGENTA	
Y		YELLOW	
S1		N/A	
S2		PANTONE 2748 C	



Assign to each patch a printing color.

In this sample patch K prints Black etc. and spot color patch S2 prints Pantone 2748 C.

Use the arrow buttons left and right to change the assignment.

4 Spot color in unit




Unit 5 prints spot color Pantone 2748 C. See

5 Go to Spot color setup

[1.3.2.1. Spot color setup](#)

1.3.2.2. Advanced Job Settings IntelliTrax

This screens is only available for IntelliTrax scanners.



1 Activate XY colorbar setup



Enable the XY setup for IntelliTrax

2 XY values

X1	0	-	+	Y1	0	-	+	X2	0	-	+	Y2	0	-	+
----	---	---	---	----	---	---	---	----	---	---	---	----	---	---	---

The XY values are explained here [1.1.1.2.1. IntelliTrax XY coordinates](#)

3 Previous XY values

Demo ITX	10	5	800	5	
----------	----	---	-----	---	--

Reuse a XY setup from a previously printed job.


4 XY Sample

See detailed sample here [1.1.1.2.2. IntelliTrax XY sample](#)

5 Return to New Job

[1.3.2. New Job](#)

1.3.2.3. Graphometronic Job Setup



1 Position Y

Colour bar position 0

Colorbar circumference position, as an offset to the standard calibrated Y position

2 Position X

Web position 0

Position across the web, roller. Use this parameter when the web is not centered in the press (e.g. shifted by 1 key) or the colorbar itself is not centered.

3 Web width

Web width 900

Web width

4 Go to New Job

[1.3.2. New Job](#)

1.3.3. Job List

Job name	Date	Scoring	Status
Demo 2	11/30/16 2:10 PM	41%	X
Demo 2	11/30/16 10:20 AM	55%	X
Demo3	11/30/16 3:15 PM	80%	X
Demo3	11/30/16 3:20 PM	67%	X
test2	10/4/16 7:47 AM	0%	X
test21	11/25/16 1:09 PM	38%	X

v4.0.0.16 Connected to Demo Instrument

1 New job



Starts a new job

See here: [1.3.2. New Job](#)

2 Import job



Import job/s

3 Export job



To export a job, select first the cross icon left of the open

4 Search / Filter



Enter a part of the job name to filter the job list

5 Job name

Job name with date and job score

6 Date / time

11/30/16
3:15 PM

Printing time and date

7 Score

Production score

8 Select job

Select a job there and then export or delete it.
See here: [1.3.3.1. Export Job](#) and [1.3.3.2. Delete Job](#)

9 Open job

Open the job in measurement view


10 Go to Delete job

[1.3.3.2. Delete Job](#)

11 Go to Export job

[1.3.3.2. Delete Job](#)

1.3.3.1. Export Job



1 Select
X

First, select the job by clicking on the grey cross. When selected it turns red.


2 Export
[Icon]

Second, select the export button and choose an export path

3 Return to Job List

[1.3.3. Job List](#)

1.3.3.2. Delete Job



1 Select
X

First, select the job by clicking on the grey cross. When selected it turns red.

2 Delete
DELETE 2 JOBS

Second, press the delete button and confirm the action.

3 Return to Job List

[1.3.3. Job List](#)

1.3.3.3. Export Job Database

The following procedure describes how to migrate the InkZoneMove job database to another computer:

IZM4 job database migration – move the installation from PC A (source) to PC B (target)

1. Install IZM4 on the target PC
2. On the target system, open http://localhost:5984/_utils/database.html?inkzone-jobs and select **Delete Database** from top commands

User name: inkzone

Password: testing

Key	Value
"14934_DSL_FUDTER_IP_10_SORTEN_20"	{...}
"199408"	{...}
"1994081111"	{...}
"199503"	{...}
"199707"	{...}
"199731"	{...}
"20401019_HAMMER_GRAFIK_WOELZEM_01_01968"-1-K"	{...}
"APPLIED_42P_BAIC"	{...}
"APPLIED_42P_BAIC_BACR"	{...}
"APPLIED_42P_BAIC_T2T"	{...}
"20401019_P-B"	{...}

Showing 1-10 of 28 rows

3. On the source system, go to

"C:\Program Files (x86)\Apache Software Foundation\CouchDB\var\lib\couchdb" (can be also "C:\CouchDB\var\lib\couchdb") and copy the file **inkzone-jobs.couch**

Then, copy all job files starting with **job_*.couch**

Name	Date modified	Type	Size
inkzone-errors.couch	08/10/2015 11:06	COUCH File	781 KB
inkzone-jobs.couch	28/01/2017 12:15	COUCH File	97 KB
inkzone-languages.couch	25/03/2016 15:30	COUCH File	100 KB
inkzone-log.couch	07/05/2014 17:18	COUCH File	9 KB
inkzone-logi.couch	29/03/2017 12:15	COUCH File	81 KB
inkzone-move.couch	28/01/2017 12:01	COUCH File	2,857 KB
inkzone-perfect.couch	24/05/2016 13:47	COUCH File	1,413 KB
inkzone-progress.couch	21/01/2017 16:42	COUCH File	4,281 KB
inkzone-scoring.couch	28/03/2017 12:05	COUCH File	117 KB
inkzone-spots.couch	28/03/2017 10:19	COUCH File	4,869 KB
job_2016-04-28-13-30-56-221.couch	03/05/2016 17:17	COUCH File	1,799,381 KB
job_2016-05-09-14-23-59.couch	03/05/2016 17:06	COUCH File	7,213 KB
job_2016-05-09-14-34-09.couch	03/05/2016 14:39	COUCH File	409 KB
job_2016-05-09-15-10-18.couch	21/03/2017 16:42	COUCH File	181 KB
job_2016-05-09-17-06-33.couch	03/05/2016 16:44	COUCH File	29,817 KB
job_2016-05-12-31-43.couch	21/03/2017 16:45	COUCH File	3,300,713 KB
job_2016-05-17-13-45-16.couch	17/05/2016 13:47	COUCH File	129 KB
job_2016-05-17-13-45-16.couch	21/03/2017 16:46	COUCH File	341 KB
job_2016-05-20-13-07-29.couch	20/05/2016 15:07	COUCH File	69 KB
job_2016-06-08-16-02-02.couch	02/09/2016 08:03	COUCH File	2,857 KB
job_2016-08-31-14-40-50.couch	21/01/2017 16:48	COUCH File	3,183 KB
job_2016-09-02-14-11-48.couch	02/09/2016 15:04	COUCH File	497 KB
job_2016-09-02-15-06-55.couch	02/09/2016 15:06	COUCH File	81 KB
job_2016-09-02-16-06-33.couch	16/09/2016 08:11	COUCH File	245 KB
job_2016-09-02-16-17-06.couch	03/09/2016 16:17	COUCH File	81 KB
job_2016-09-03-14-11-01.couch	03/09/2016 14:26	COUCH File	7,189 KB
job_2016-09-03-14-40-02.couch	16/09/2016 08:08	COUCH File	10,641 KB

254 items 1 item selected

4. On the target system, open the CouchDB storage folder (same as from point 2) and paste the **inkzone-jobs.couch** and the **job_*.couch** files.

5. Start InkZoneMove. All jobs should be fully functional now

1.4. IZReport

InkZone Report is an add-on for InkZoneMove to verify print jobs against a given print standard, print reference. For none InkZoneMove user the application can be configured to process X-Rite SVF data or Scan.XML JDF data.

1.4.1. Setup

InkZone Report uses target and scoring sets for the color assessments. For the report configuration it's important to understand targetset: [1.2.3.3. Edit Targetset](#) and scoring setup: [1.2.5. Scoring Setup](#)

1.4.2. Views

InkZoneReport has different views on job measurement data.

Go to:

- [1.4.2.1. Job list](#)
- [1.4.2.2. Production Report Summary](#)
- [1.4.2.2. Production Report Summary](#)
- [1.4.2.3. Sheet Report Summary](#)
- [1.4.2.4. Sheet Reports](#)
- [1.4.2.5. Trend on Density](#)
- [1.4.2.6. Trend on Lab and TVI](#)
- [1.4.2.7. Sheet Reports with Lab](#)
- [1.4.2.8. PDF output](#)

1.4.2.1. Job List

Job list

Job info

Start date / time

Total score

Open in IZMove

Show report

Select job


Go to Report Views

Job name	Date	Scoring
Cover_Illu_12398 Rexton	23/08/17 14:55	95%
08 AGOSTO_1A_CMYK	09/08/17 10:56	72%
test scan 1 to 6 nr2	07/06/17 15:46	32%
test scan 1 to 6	07/06/17 15:35	51%
1464223 Abbott	05/06/17 11:04	35%
Job 2987 Rotas	05/06/17 10:54	32%
181043-02	07/04/17 10:21	43%
Photoset 3	20/02/17 07:42	66%
S/E test export	02/02/17	

v4.2.0.16

Connected to Demo Instrument

1 Job list



Access job list

2 Job info

Cover_Illu_12398

Rexton

Job and customer name

3 Start date / time

23/08/17

14:55

Job's start date and time

4

Total score



Total job score calculated from target and scoring set

5

Open in IZMove



Open job in InkZoneMove measurement view (only when IZMove is available)

6

Show report



Open report summary

7

Select job




Select a job for export or removal.

8

Go to Report Views

[1.4.2. Views](#)

1.4.2.2. Production Report Summary



1 PDF creation



Create a PDF report printout. Tab on the icon and select the report type. Details see here:
[1.4.2.9. PDF output](#)

2 Summary



Access report summary

3 Job information

Name	AGRI NK - KONGRESBLAD
Customer	
Created at	04.07.2017 12:08

Displays job and customer name with start date and time.

4 Measurement information

Production targetset PSO_P1_B_25-50-75_v2	
Scoring	ISO 12647
Scan parameters	D50 / O2

Displays time for MakeReady and Production and job's final measurement which marks job end.

5 Production score

87%

Total score on job production according to its target and scoring set.

6 Solid color

Read columns like:

Summary	1	2	3	4	5
	Print / Target [L a b]	D	ΔE / Tol	ΔE	≡
Black	16.0 / 16.0	0.8 / 0.0	1.9 / 0.0	1.80	5.4 / 5 100% 100%
Cyan	54.4 / 54.0	-35.9 / -36.0	-50.4 / -49.0	1.50	1.7 / 5 100% 100%
Magenta	49.0 / 46.0	74.8 / 72.0	-4.5 / -5.0	1.39	4.5 / 5 100% 100%
Yellow	87.9 / 87.0	-5.8 / -6.0	88.7 / 90.0	1.31	2.8 / 5 100% 100%
Red (M+Y)	48.5 / 46.0	68.5 / 67.0	45.8 / 47.0	1.53	3.9 / 10 100% 100%
Green (C+Y)	49.0 / 49.0	-68.7 / -66.0	21.7 / 24.0	1.46	3.8 / 10 100% 100%
Blue (C+M)	25.3 / 24.0	16.8 / 16.0	-46.8 / -45.0	1.45	2.7 / 10 100% 100%
Paper	93.4 / 93.0	1.1 / 0.0	-2.7 / -3.0	0.00	1.3 / 3 100% 100%
					6 23%

[1] Print / Target [Lab] : printed value in bold, target values in light color tone

[2] Density : target density

[3] Delta E / Tolerance : deltaE of printed color in bold, accepted tolerance for assessment in light color tone

[4] Delta E score : scores for deltaE with the selected scoring set

[5] Dot gain score : scores for dot gain values with the selected scoring set


[6] Midtone spread: scores for mid-tone spread

7 Overprint

Red (M+Y)	48.5 / 46.0	68.5 / 67.0	45.8 / 47.0	1.53	3.9 / 10	100%
Green (C+Y)	49.0 / 49.0	-68.7 / -66.0	21.7 / 24.0	1.46	3.8 / 10	100%
Blue (C+M)	25.3 / 24.0	16.8 / 16.0	-46.8 / -45.0	1.45	2.7 / 10	100%

Score on overprints (secondary colours)

8 ab color circle



Colour gamut with CMY and RGB coordinates.

9 Paper

Paper	93.4 / 93.0	1.1 / 0.0	-2.7 / -3.0	0.00	1.3 / 3	100%
-------	-------------	-----------	-------------	------	---------	------


Score on paper (DeltaE on Lab)

10 Mid-tone spread



Score on CMY mid-tone spread

11 Dot gain




Tone value increase cure with print result and tolerance area.

12 Go to Report Views

1.4.2. Views

1.4.2.3. Sheet Report Summary



1 PDF creation



Create a PDF report printout. Tab on the icon and select the report type. Details see here: [1.4.2.9. PDF output](#)

2 Sheet report



Access report summary

3 Sheet information

Number	1
Side	Front
Created at	18.09.17 12:10

Displays job and customer name with start date and time.

4 Measurement information

Production targetset	ISO 12647-2 -couché
Scoring	ISO 12647
Scan parameters	D50 / O2

Displays time for MakeReady and Production and job's final measurement which marks job end.

5 Sheet score

72%

Total score on job production according to its target and scoring set.

6 Solid color

Read columns like:

Summary	1	2	3	4	5
	Print / Target [L a b]	D	ΔE / Tol	ΔE	≡
Black	16.0 / 16.0 0.8 / 0.0 1.9 / 0.0	1.80	5.4 / 5 75%	100%	
Cyan	54.4 / 54.0 -35.9 / -36.0 -50.4 / -49.0	1.50	1.7 / 5 100%	100%	
Magenta	49.0 / 46.0 74.8 / 72.0 -4.5 / -5.0	1.39	4.5 / 5 100%	83%	
Yellow	87.9 / 87.0 -5.8 / -6.0 88.7 / 90.0	1.31	2.8 / 5 100%	100%	
Red (M+Y)	48.5 / 46.0 68.5 / 67.0 45.8 / 47.0	1.53	3.9 / 10 100%	100%	
Green (C+Y)	49.0 / 49.0 -68.7 / -66.0 21.7 / 24.0	1.46	3.8 / 10 100%	100%	
Blue (C+M)	25.3 / 24.0 16.8 / 16.0 -46.8 / -45.0	1.45	2.7 / 10 100%	100%	
Paper	93.4 / 93.0 1.1 / 0.0 -2.7 / -3.0	0.00	1.3 / 3 100%	100%	
					6 100%

[1] Print / Target [Lab] : printed value in bold, target values in light color tone

[2] Density : target density

[3] Delta E / Tolerance : deltaE of printed color in bold, accepted tolerance for assessment in light color tone

[4] Delta E score : scores for deltaE with the selected scoring set

[5] Dot gain score : scores for dot gain values with the selected scoring set


[6] Midtone spread: scores for mid-tone spread

7 Overprint

Red (M+Y)	50.4 / 46.0	65.2 / 67.0	46.5 / 45.0	1.45	4.6 / 9	100%
Green (C+Y)	48.5 / 49.0	-68.1 / -63.0	21.0 / 25.0	1.49	2.6 / 9	100%
Blue (C+M)	28.4 / 24.0	9.6 / 20.0	-49.7 / -45.0	1.54	9.8 / 8	0%

Score on overprints (secondary colours)

8 ab color circle



Colour gamut with CMY and RGB coordinates.

9 Paper

Paper	96.2 / 93.0	0.9 / 1.0	-2.5 / -5.0	0.01	2.9 / 4	100%
-------	-------------	-----------	-------------	------	---------	------

Score on paper (DeltaE on Lab)


10 Mid-tone spread



33%

Score on CMY mid-tone spread

11 Dot gain




Tone value increase curve with print result and tolerance area.

12 Go to Report Views

1.4.2. Views

1.4.2.4. Sheet Reports



1 Sheet reports



Access sheet report

2 Scan information

Sheets scanned	87
Final measurement date	19.09.17 10:33

Total scan measurement, including MakeReady, and the time when the last measurement was taken

3 Scan number and time

87	10:33
86	10:32

Measurement number and time.

A click on a measurement brings you further to the DeltaE sheet report [1.4.2.6. Sheet report DeltaE](#)

4

Scoring on criteria

Scoring for every criteria:

- solid color CMYK - deltaE
- TVI
- overprint - deltaE
- paper - deltaE

5

Total sheet score

Total scoring for selected sheet

6

**MakeReady
indicator**

A grey background indicates that the sheet was measured during MakeReady.

7

Go to Report View

[1.4.2. Views](#)

8

Select for IZTVI

Select here the measurement data to be exported to InkZoneTVI for CTP plate compensation.
After selecting one or more measurement, press the button above "Export to IZ TVI".


9

Export to IZTVI

After selecting one or more scan measurement, see "Select from IZTVI", the export button gets visible.
Press the button and the selected dataset are exported for InkZoneTVI. A data average is created if more than one scan is selected.

1.4.2.5. Trend on Density

A density trend graphs displays the spread and average density for every measurement.




1 Density trend



The density trend graphs displays the spread and the average density for every measurement.

2 Spread and average



Indicates average density (horizontal) and spread (vertical).

Example:


Measurement number 5 has an average of 1,8 and a density spread from 1.55 to 2.0 which is the lowest and highest density reading from the black color.

3 Go to Report View

[1.4.2. Views](#)

1.4.2.6. Trend on Lab and TVI

Shows Lab trend for primary and secondary colours, trend for TVI plus the mid-tone spread.



1 Trend



Opens trends

2 Primary, Secondary colours


- Black
- Cyan
- Magenta
- Yellow

- Blue (C+M)
- Green (C+Y)
- Red (M+Y)

Click on a colour here to toggle it on or off in the graph.

3 Diagram


Display of a color is toggled on and off by clicking on the color's name on the right.




- 1) DeltaE scale
- 2) Measurement number and time stamp
- 3) Grey area = status MakeReady mode
- 4) White area = status Production mode
- 5) Green area = tolerance

4 TVI percentage

Depending on the target and scoring setup the trend for the TVI percentage are shown here.



5 TVI diagram



- 1) TVI percentage scale
- 2) Toggle diagram colours on and off
- 3) Tolerance area

6 Mid-tone spread

● Midtone spread

CMY mid-tone spread

7 Go to Report View

1.4.2. Views

1.4.2.7. Sheet Reports with Lab

Report on every sheet with DeltaE on primary and secondary colours.

	Target [L a b]	Print [L a b]	DeltaE	Tolerance	In target
Black	16 0 0	12.48 -0.52 -1.96	9.41	5	3.45%
Cyan	54 -36 -49	54.66 -34.85 -48.61	1.76	5	100%
Magenta	46 72 -5	50.66 67.84 -8.09	7.02	5	0%
Yellow	87 -6 90	86.25 -6.68 67.27	22.8	5	0%
Blue (C+M)	24 16 -45	30.09 9.21 -45.24	9.13	10	100%
Green (C+Y)	49 -66 24	49.91 -58.06 0.69	24.68	10	0%
Red (M+Y)	45.99 67 47	50.33 59 29.74	19.83	10	0%

	Target [L a b]	Print [L a b]	DeltaE	Tolerance	In target
Black	16 0 0	17.52 0.53 1.1	7.39	5	41.38%
Cyan	54 -36 -49	53.86 -35.3 -50.02	1.66	5	96.43%
Magenta	46 72 -5	47.16 73.72 -3.3	3.01	5	92.86%
Yellow	87 -6 90	85.09 -4.34 91.84	5.02	5	71.43%
Blue (C+M)	24 16 -45	25.68 16.42 -45.03	1.91	10	100%
Green (C+Y)	49 -66 24	47.98 -63.47 26.89	4.25	10	100%
Red (M+Y)	45.99 67 47	47.21 64.92 48.29	3.39	10	100%

v4.2.0.16 Connected to Demo Instrument

1 DeltaE sheet report

ΔE

Opens DeltaE report for every measured sheet

2 Sheet number and date / time

1: 23/08/17 14:55

Indicates sheet number and date and time

3 Target Lab

Target [L a b]		
16	0	0
54	-36	-49
46	72	-5

Target Lab for all printed colours

4

Measured Lab

Print [L a b]		
12.48	-0.52	-1.96
54.66	-34.85	-48.61
50.66	67.84	-8.09

Average Lab from all measured patches

5

Colour difference

DeltaE
9.41
1.76
7.02

DeltaE from target and measured patches

6

DeltaE tolerance

Tolerance
5
5
5

Tolerance for every colour, set in targetset

7

Assessment

In target
3.45%
100%
0%


Displays number of patches in target [in percentage] with pass, fail indication

8

Go to Report Views[1.4.2. Views](#)

1.4.2.8. PDF output

Print sheet or production report.



1

PDF output



Start here to create a PDF sheet or production report

2

Setup

Print reports

Print settings

Report type	Print Production-Report
Template	Standard
Paper size	A4
Send email	<input checked="" type="checkbox"/>

Report Type

- 1) Production report
- 2) Single sheet report

Template

Select a PDF report template.

Setup a template here [1.2.8.8. PDF Report Template](#)

Paper size

- 1) A4
- 2) Letter

Label print

On or off

Creates a narrow sized PDF to print on a label printer

3

Go to Report Views

[1.4.2. Views](#)

4

Go to PDF Report Template

[1.2.8.8. PDF report template](#)

5

Sample reports

[Sample](#)

FAQ section

Find here a collection of frequently asked questions.

Installation

[Startup error MSVCR100.DLL](#)

[How to migrate the job database to another computer?](#)

[Computer with 2 monitors](#)

Setup

[Send e-mail with Google Mail server](#)

[Exclude paper white patches with Intellitrac](#)

[Shifted ink-key alignment](#)

[Set density threshold to disable ink-key adjustment](#)

How to migrate the job database to another computer?

See here [1.3.3.3. Export Job Database](#)

Computer with 2 monitors

InkZoneMove should appear on the 2nd monitor. How to configure?

Press CTRL + ALT + 2 . Return to monitor 1 with CTRL + ALT + 1

Send e-mail with Google Mail server


a) Setup

```
# Gmail SMTP server address: smtp.gmail.com
# Gmail SMTP username: Your Gmail address (e.g. example@gmail.com)
# Gmail SMTP password: Your Gmail password
# Gmail SMTP port (SSL): 465
```

If you can't send mail with your Gmail account for that reason, it's unlikely that you're entering the wrong SMTP settings. Instead, you'll get a message related to the security of the email client.

To solve this, log in to your Google account through a web browser and [enable access through less secure apps through this link](#).

If that is not the reason Gmail isn't working in your email client, see [How to Unlock Gmail for a New Email Program or Service](#).




b) Verify SSL connection with OpenSSL for Windows

1. Download OpenSSL for Windows from sourceforge: <https://sourceforge.net/projects/openssl/>
2. Copy folder OpenSSL to c:\OpenSSL
3. Start openssl.exe from C:\OpenSSL\bin
4. Connect to the smtp server:
OpenSSL> s_client -connect smtp.gmail.com:465 -crlf
The complete procedure is described here: <https://taufanlubis.wordpress.com/2016/02/08/how-to-send-email-via-gmail-server-using-openssl/>

```
C:\OpenSSL\bin\openssl.exe
WARNING: can't open config file: C:/OpenSSL/openssl.cnf
OpenSSL> s_client -connect smtp.gmail.com:465 -crlf
CONNECTED(000001DC)
depth=1 C = US, O = Google Trust Services, CN = Google Internet Authority G3
verify error:num=20:unable to get local issuer certificate
---
Certificate chain
  0 s:/C=US/ST=California/L=Mountain View/O=Google LLC/CN=smtp.gmail.com
    i:/C=US/O=Google Trust Services/CN=Google Internet Authority G3
  1 s:/C=US/O=Google Trust Services/CN=Google Internet Authority G3
    i:/OU=GlobalSign Root CA - R2/O=GlobalSign/CN=GlobalSign
---
Server certificate
-----BEGIN CERTIFICATE-----
MIIEgjCCA2qAwIBAgIITzPNiiDpglAwDQYJKoZIhvcNAQELBQAwVDELMakGA1UE
BHNCVVMxhJAcBgNVBAoTFCvb2dsZSBucnVzdCBTZJ2sWNLczElMCNga1UEAxMc
R29vZ2xlEludGVybmlv0IEF1dGhvcmle5BHMzAeFw0xODA4MDcxODM4NDVaFw0x
ODExMTYxODI4MDBaMGgxSzAJBgNVBAYTAlVTMRMwEQQDVQQIDapDWxpZm9ybmlh
MRYwFAYDVQQHDA1Nb3VudGFpbjBWAwV3MRMwEQQDVQQKDAphb29nbGUgTEXDMRcw
FQYDVQOQDA5zbXRwLmdtYw1slmNvbTCASlwdQYJKoZIhvcNAQEBBQADggEPADCC
AQoCggEBALZ6yD2mrwQUOps/g+MhejCdzb9viOk/cSL9g4HEmJ42UrwbKEB0joOf
JYncdHyd1dTgtHZJ0CuhyKXuwqlPKnM1RpERSOviQ262GTSXX8KPvF/f0whF7h
5CeuaNIpVmjP2u16VPn/guzzGz6dxmZPjucSG56eG7GhevWMCOxDa88FPn4
YAnp5Z0EWBAUWumAaAskUha0bvSvm0ob/lSAMz4bp0W1UDebwBRpaIn3EyiaPO
aJXOMOpSoy7sVKgqklss6W45B53uw+1CWrpwhvD026Kyh016hMwJcgxFXC/V7Qp
aiHgMwYbgwn7P0V2KU+wh1v/B0tM5RMCAwEAAoCAUJTwggE+HBMwGA1UdJQQwMAoG
CCsGAQUBBwMBMBkgA1UdEQ0SMBBCDnNtdHAuz21haNwuY29tMggGCCgGAQUBwEB
BFmwijAtBgr8gEFBQcwAoYhaHR0cDovL3Bra55nb29nl.2dzcjIvR1RTR01BRzMu
Y3J0MCKGCCgGAQUBBzABhh1odHRw0i8vb2NzcC5wma2kuZ29vZy9HFNFHSUFHmzAd
BgNw04EfQUP8juifQfd5wSNq6I9svP21TmPLhwDAYDVR0TAQH/BAIwADAfBgNV
HSMEGDAwgbR3wrhQmmdd2rEtwoBQg6B+pn66SzAhBgWHSAGjAYMAwGCisGAQQB
InkCBQMuCAYGZ4EMAQICMDEGA1UdhwQoMCgwJqAkoCKGIGH0dHA6Ly9jcmwucGtp
Lndvb2cvr1RTR01BRzMuY3JssNA0GCSqGSIb3DQEBCwUA4IBAQCa8RwF77uzMvh
8fhv1Y0QFN1Zy1C0Oq5FBzjy+aABm3U/e0wiYov39+Z6IQvt44NMNIW3H9aKAA
dlu7CHKbzV37V3JW/iT0frNsES8s0tDl07dhobTpnimFY1XTCUelz7QBhTt810
yp4cPYe5Z9PKbxqa9qc9UlaskxLG668yuHE+RYk448g839hg1wRcIvjXipyYPlY65
ZKnh2bugShijYvxHdy16K8Zkqar9EIdZsy21BeRrK3vItdmvyMA0w3kH/opIm37
bdefCaJI/JkjBoXWj6VO4Qlivh9nZNP1LnE6QgZ2fvD8J5h8Wayo7i203diq4fnY
c5nJmDCU
-----END CERTIFICATE-----
subject=/C=US/ST=California/L=Mountain View/O=Google LLC/CN=smtp.gmail.com
issuer=/C=US/O=Google Trust Services/CN=Google Internet Authority G3
---
No client certificate CA names sent
Peer signing digest: SHA256
Server Temp Key: ECDH, P-256, 256 bits
---
SSL handshake has read 2986 bytes and written 434 bytes
---
New, TLSv1/SSLv3, Cipher is ECDHE-RSA-AES128-GCM-SHA256
Server public key is 2048 bit
Secure Renegotiation IS supported
Compression: NONE
c5nJmDCU
```

Exclude paper white patches with Intellitrx

Certain papers types can cause an incorrect reading of the leading paper white area on the sides of the colorbar. The sample below shows a paper white patch at the end of the measured colorbar which should be excluded.



There is a **L threshold** setup to exclude such patches on both sides of the colorbar.

Open the database with this link:

http://localhost:5984/photon/_design/photon/index.html#inkzone-central/instrument_SpectroDens

Go to the entry and change:


First_bad_patches_L_min

First_bad_patches_L_max

Shifted ink-key alignment


Use the following setup parameters when the colorbar is not printed centred over press machines ink-keys.

1) Setup press with “shifted” ink-key alignment




- 1) Advanced press settings
- 2) Choose centred and shifted

2) Job setup



- 1) During job setup, choose extended job setting.
- 2) Select shifted
- 3) Select the ink-key number where the color bar starts
- 4) Select an offset of 0 or ¼ or ½ or ¾ within the selected ink-key (selected at 3)


3) Change colorbar parameter during print



- 1) Select colorbar menu
- 2) Set-up the colorbar positioning parameter

Startup error MSVCR100.DLL

The X-Rite eXact DLL requires a DLL from the Microsoft Visual C++ 2010 Service Pack 1.
If the DLL is missing, InkZoneMove throws an error during startup:



Update or install the DLL from the Microsoft website, [click here](#).

Prevent ink-key adjustment with a density threshold parameter

Go to the InkZoneLoop setting in the system setup: [1.2.7. System Setup](#)